



We always adhere to the "quality first, lean production, provide customers with quality products and services" business policy, from production control to packaging are subject to the most stringent quality measures, committed to the industry-leading Isuzu auto parts brand.

Chongqing Guanglian Qingling Auto Parts Co., Ltd

Tel: +86 173 8315 2089
Web: www.comlenisuzu.com



Auto Parts for **Japanese Truck**

Mainly Qingling Auto Japan, Qingling, Brand Parts



Pan Yuncai
General Manager



29+ YEARS FOCUS ON ISUZU TRUCK PARTS

+86 17383152089  

 ZCMisuzu@guanglian99.com

 <https://www.isuzucomlen.com>

 <https://cqguanglian.en.alibaba.com>

 No.5-9,street front shop of apartment building D AreajiuzhouInternational Automobile City, Jiulongpo District, Chongqing



WhatsApp



WeiXin

Chongqing Guanglian Qingling Auto Parts Co., Ltd.



Company Profile

28 years of experience
in truck parts

factory
overview



Founded in 1997, Chongqing Guanglian Qingling Auto Parts Co., Ltd. is located in Baishiyi Jiulongpo District, Chongqing, China. We are one of the largest truck parts distributor in China.

We mainly sell full spare parts for heavy truck, model cover: ISUZU(NPR NKR ELF FRR FTR GIGA D-MAX), HINO(300 500 700), MITSUBISHI(FUSO CANTER), main products are China Qingling Isuzu original parts and Japanese truck original parts, also supply spare parts for European truck model Benz Volvo Scania Man etc.

Since its inception, the company has always adhered to the "quality first, reputation first, efficient and efficient, dedicated service" business philosophy. With the professionalism of the sales team, the stability of high-quality products, and the long-term service of efficient service, it has won the recognition and reputation of customers. Through technology introduction and first-class management level and perfect after-sales service system, the company has established a strong network marketing system at home and abroad, and has close cooperation and trade with hundreds of companies. The products are exported to the United States, Europe, Africa, and other international markets.



The Factory is located in Baishiyi Jiulongpo District, Chongqing, China.



Looking forward to the future, we keep a modest and prudent attitude to provide more premium products, and strive to become the top auto parts supplier in the world.

CHONGQING GUANGLIAN
QINGLING
AUTO PARTS CO.,LTD



PROFESSIONAL TRUCK
PARTS MANUFACTURING AND EXPORT

· ISUZU TRUCK
· EUROPEAN TRUCKS

COMLEN

BRAND SERIES PARTS

Striving For Excellence
And Ensuring Quality



01 动力系统 ENGINE PARTS



8-97436494-0
Engine Assy
发动机总成
RZ4E



Engine Assy
发动机总成
4HK1



Engine Assy
发动机总成
4JB1T



Engine Assy
发动机总成
4KH1




Partial Engine
凸机
4JJ1/4JK1



Long Block
凸机.长缸体
4HK1



Long Block
凸机.长缸体
6HK1



Short Block
中缸
6HK1



SHORT BLOCK
中缸
4JJ1/4JK1



8-98085312-0
Cooler Assy; Oil
机油冷却器总成
NPR/4HK1T



8-98212718-1
EGR Cooler Assy
EGR冷却器
FRR/NPR/700P



8-98025248-0
EGR Cooler Assy
EGR冷却器
FRR/NPR/700P



8-97430590-0
EGR Cooler Assy
EGR冷却器
CXZ/6UZ1-T



8-97968622-0
EGR Cooler Assy
EGR冷却器
Giga 6WG1T



8-98030582-4
EGR Cooler Assy
EGR冷却器
FVR/6HK1



8-97383005-9
EGR Valve
EGR阀
FVR34/6HK1-T



8-98144274-1
EGR Valve
EGR阀
NKR/NPR



8-97435557-1
EGR Valve
EGR阀
TFR/TFS



8-98098257-5
EGR Valve
EGR阀8P
NPR/4HK1



8-97379625-6
EGR Valve
EGR阀
NQR/4HK1



8-97381560-7
EGR Valve
EGR阀
NKR/NPR/NHR/4JJ1



8-97115533-3
EGR Valve
EGR阀
NPR/4HG1



8-98040003-4
Valve Assy; Throttle
节气门总成
NKR/4KH1T



8-98028416-7
Throttle Valve
节气门总成
FRR/NPR/700P



8981600613
Nozzle Asm; Inj
喷嘴总成
NPR/FTR/FVR/4HK1/6HK1



8-97609789-4
Fuel Injector Assembly
燃油嘴总成
FTR/FVR/700P



8-97609788-7
Fuel Injector Assembly
燃油嘴总成
FRR/NPR/700P



0445110845
Nozzle, Injector
燃油嘴总成
NKR/4KH1



8-98145449-1
Overhaul kit; supply pump
油压传感器
FTR/700P



8-98145501-1
Overhaul kit; supply pump
油压传感器
NPR/700P



8-98145501-1
Overhaul Kit; Supply Pump
传感器
NPR/FVR/4HK1/6HK1



8-98119790-1
Sensor; Press
共轨管传感器
NPR/FVR/4HK1/6HK1



8-98009418-0
Map Sensor (intake pressure)
进气压力传感器
NPR/700P/FVR/VC



8-98020514-0
Press Sensor 3P
压力传感器3P
FVR/TFS/VC/700P



8-97312108-2
Crankshaft Sensor
传感器
NKR/4KH1



8-97606943-0
Crankshaft Sensor 3p
曲轴位置传感器
CYZ/EXR/FRR/NPR



8-98019024-0
Sensor 3P (Camshaft)
偏心轴位置传感器
TFS/FVR/700P



8-97601967-1
Manifold Sensor 5P
空气流量计 (5P)
NKR/NPR/FVR/TFS/700P



8-98032549-0
Common Rail Pipe Pressure Limiting Valve
共轨管限压阀
FRR/FVM/NLR/700P



8-98173342-0
Jet; Oil
活塞喷嘴
FTR/FSR/NPR/700P



8-98011888-2
Common Rail Assy
共轨管
FRR/NPR/TFS/700P



8-98017585-1
Oil Pump
机油泵
NPR/4HK1/4HF1



8-97431877-0
Oil Pump
机油泵
VC61/6WG1



8-98017585-1
Oil Pump (TBK)
机油泵
FRR/NPR/700P



8-97308115-2
Oil Pump (TBK)
机油泵
NKR/NKR



J05E
Water Pump
水泵
HINO



N04C-VB
Water Pump
水泵
HINO



8-97363478-1
Water Pump (TBK)
水泵 (TBK)
700P



16100-2955
Water Pump
水泵
HINO



1-87310835-0
Water Pump (TBK)
水泵
FVZ/FTR/GVR



8-97334100-1
Oil Cooler Core
机油冷却器芯
FRR/NPR/700P



8-98190148-1
Fan Clutch
风扇叶带耦合器
NPR/4HK1T



8-98019743-1
Cooling Fan Clutch
风扇耦合器
NPR/FTR/700P



8-97430634-0 8-98071042-0
Clutch Fan
风扇叶耦合器
CXZ/CYZ/6UZ1/6WG1



8-97434968-0
Clutch Fan
风扇叶耦合器
CXZ/CYZ/6WG1-T



8-97139299-0
Clutch Fan
风扇叶耦合器
NPR/NQR/4HG1



8-97129735-1
Clutch Fan
风扇叶耦合器
NKR/4KH1



8-98027772-2
Turbocharger
涡轮增压器
NPR/700P



8-97377509-8
Turbocharger
涡轮增压器
NKR/NPR/TFS



8-97040454-0
Distributor Assembly
分电器总成
TFR/TFS/VCS



KYJGGQFXLB-4HK1
Air pump repair kit
打气泵修理包
NPR 4HK1



KYJGGQFXLB-6HK1
Air pump repair kit
打气泵修理包
FVR/6HK1



8-97139603-0
Thermostat Housing
节温器座
NKR/4JB1-T



8-97329914-0
Thermostat Housing
节温器盖
FRR/NPR/700P



8-97073924-0
Generator Assy
发电机总成
NKR/4JB1



8-97433238-0
Generator Assembly
发电机总成
VC61/6WG1



8-97432970-0
Generator Assembly
发电机总成 (24V)
CXZ/VC



8-98075026-2
Generator
发电机总成
NPR/NQR/700P



8-97357613-0
Resistor; 2P
电阻 2P
CYH/EXZ/FVR/VC/NPR



3705110-54H
Ignition Coil Assy
点火线圈总成
TFR17/4ZE3



8-97072947-0
Switch; Oil Pressure
机油感应器
NKR/4JB1



8-97311976-0
Valve; Relief,oil Pump
缸体喷油管阀
TFR 4JB1T



8-98009043-0
Starter Assembly
起动机总成
NPR/FTR/700P



8-98054984-0
Starter Assembly
起动机总成
NQR/NPR/700P



8-98187304-2
Air Compressor
打气泵总成
FTR/FVR



8981401639
Compressor Asm; Air
打气泵总成
LE60/4HK14HG1




8-97300790-3
Thermostat B (Mahle)
节温器B
FRR/FVZ/700P



8-97300787-3
Thermostat A (Mahle)
节温器A
FRR/FVZ/700P



8-97602048-2
Thermostat
节温器A
FRR/FVR/FVM



8-98295921-1
Thermostat
节温器B
FRR/FVR/FVM



1-19110075-0
Head Asm; Air CMPR
打气泵缸盖
NPR/4HK1



8-97614055-0
Head Asm;CYL;AIR CMPR
打气泵密封垫
FSR/FVM/FVZ



1-19115015-0
Gasket; Air CMPR
打气泵密封垫
FTR/4HK1



1-19115016-0
Gasket; Air CMPR
打气泵密封垫
FTR/4HK1



8-98319254-9
Thermostat
节温器
CXZ/6UZ1



8-97361770-1
Thermostat (Mahle)
节温器
NHR/NKR/TFS/VCS



094040-0081
High Pressure Pump Valve Body
高压泵阀体芯
VC61/6WG1



094150-0318
High Pressure Pump Valve
Body Assembly
高压泵阀体总成
VC61/6WG1



5-87813193-0
Cylinder Liner Kits
缸套组件
NKR/NPR/TFS




8-98014046-0
Cylinder Liner Kits
缸套组件
NPR/FVR/700P



8-98041062-0
Piston
活塞
CXZ/NPR/FVR/700P



8-97108621-0
Piston D=34 (dome)
活塞
NKR/TFS/VCS



8-94247867-2
Piston Ring STD
活塞环
NKR/TFR/VCS



8-97259941-1
Piston Ring
活塞环
NKR/4KH1



8-97372078-1
Crankshaft Bearing
曲轴瓦
FRR/FVZ/NPR/700P



8-98029270-0
Crankshaft
曲轴
FRR/NNR/700P



8-97262166-0
Camshaft
凸轮轴
FRR/NPR/ELF



8-97146499-2
Exhaust Manifold to Head Gasket
排气歧管垫
FRR/NPR/NLR/700P



8-97209876-3
Exhaust Valve
排气门
FRR/FVR/NKR/700P



8-94395882-5
Intake Valve (Mahle)
进气门
FTR/FVR/NPR/700P



8-97209876-3 8-97131729-3
Exhaust And Intake Valves
进排气门
NPR/NKR



8-97210702-0
Valve Seal
气门油封
FRR/NPR/700P




8-97120307-0
Valve Guide Seal
气门油封
NKR/FFR/VCS



1-87618505-0
Seat Spr
气门座
700P/FVR/4HK1/6HK1



5-87818556-2
Full Set
发动机大修包
NPR/700P



8-97331185-0
Head Gasket
气缸床
NKR/NPR/NQR




8-98288503-0
Cylinder Head Gasket
气缸床 T=1.575
ELF/NPR/NQR/700P



8-94369518-0
Seal; Oil,crankshaft
曲轴前油封
NPR/4HK1



8-98334339-0
Crankshaft Rear Oil Seal
曲轴后油封
CXZ/NPR/FVR/700P



8-97329780-0
Crankshaft Front Oil Seal
曲轴前油封
FRR/FSR/NPR/700P




8-97071561-0
Crankshaft Oil Seal; RR
曲轴后油封
NKR/NQR/TFS



1-09639034-1
Gasket; Cover
高压泵钢管油封
NPR/4HK1/6HK1



8-94390777-4
Glow Plug
预热塞
FRR/FSD/NPR/700P



8-97364386-0
OIL PAN GASKET
油底壳垫
NPR/700P



8-98004329-0
DPD sensor
排气温度传感器1
NPR/FVR/CXZ/700P



8-98004330-0
DPD sensor
排气温度传感器2
NPR/FVR/CXZ/700PDPD



1-87610101-0
Fan Belt
风扇皮带
FRR/FTR/VC



5-87610058-0
8-98003187-0
Fan Belt
风扇皮带
NLR/NPR/ELF/NJR



8-98010841-0
Air Conditioner Belt
冷风机皮带
FTR/700P



8-94108204-0
Belt; Ac Cmpr
冷气机皮带
NKR55/4JB1



8-97600586-1
Idle Gear (A) Z=30:30
过桥齿 (A) Z=30:30
FRR/FVR/700P



8-94394342-4
Crankshaft Gear Z=42
曲轴齿 (Z=42)
FRR/FVZ/NPR/700P



8-97120005-0
Idle Gear (D) (Z=34)
过桥齿 D (Z=34)
CXZ/FRR/NPR/700P



8-98018935-3
Camshaft Gear (Z=35)
偏心轴齿
FRR/FVR/NPR/700P



5-87610009-0
Oil Filter
机油滤芯
NKR/TER



8-97329911-0
Oil Filter
机油滤芯
NKR/NKR77



8-97431167-0
Oil Filter
机油滤芯
GIGA/6WG1



8-97625725-0
Oil Separator Filter Element
机油分离器滤芯
CYZ/EXZ/FXR/VC



8-94139761-0
Idle Gear (B) Z=37
过桥齿 (B) Z=37
NKR/TFR/VCS



8-94139754-0
Crankshaft Gear Z=21
曲轴齿 Z=21
NKR/TFR/VCS



8-94139759-0
Idle Gear (A) Z=31
过桥齿 (A) Z=31
NKR/TFS/VCS



8-97079212-0
Camshaft Gear Z=42
偏心轴齿
NKR/TFS/VCS



8-97431167-0
Oil Filter Element (Large)
机油滤芯 (大)
CYZ/EXZ/VC



8-97431166-0
Oil Filter Element (Small)
机油滤芯 (小)
CYZ/FXZ/VC



8-98272997-0
Diesel Filter Element (Coarse)
柴油滤芯 (粗)
CYZ/VC/FVR



8-98273233-0
Diesel Filter Element (Fine)
柴油滤芯 (细)
CYZ/EXZ/VC



8-97186398-0
Idle Gear Shaft (c)
过桥齿座 (C)
FRR/FVR/NKR/700P



8-97350021-0
Idle Gear Shaft (B)
过桥齿座 (B)
FRR/FVZ/NPR/700P



8-94395314-3
Crankshaft Pulley
曲轴皮带轮
FRR/FSR/700P



8-94472349-0
Pulley; Tensioner
时规带张紧轮
TFR/4JB1



1-87610093-4
Fuel Filter
柴油滤芯
NPR/FRR/FVR/700P



8-98194119-0
Fuel Filter
柴油滤芯
TFR/NKR/NPR



1-87810976-0
Diesel Filter Element
柴油滤芯 (细)
CYH/EXR/FVR/VC



8-98106579-0
Element, Filter
机油分离器滤芯
FVR/FSR/FRR/6HH1



8-98035085-0
Alternator Bracket
发电机支架
NPR/NLR/4HK1/4HF1



8-97134600-0
Adjust Plate
发电机支架
TFR/4JB1



8-97080556-1
Adjuster Plate
发电机支架
NKR/4JB1



8-97075884-0
Bracket; Gen
发电机支架
NPR/4HK1



8-94156052-0
Air Filter Element
空气滤芯
NKR/NPR/NQR



8-97431711-0
Air Filter
空气滤芯 (内外)
Giga/6UZ1/6WG1



1109241-NE15A
Air Filter
空气滤芯
KV/4KH1



8-98050415-1
Air Filter Assembly (housing)
空气滤清器总成
NPR/700P



ISUZU

			
8-98095980-0 Fuel Filter Assembly 油水分离器 FRR/FVZ/700P	8-98162904-3 Fuel Sedimentor 油水分离器 FTR/FVR/700P	8-98162904-3 Oil-Water Separator 油水分离器 FVR/FTR/6HH1/6HK1	8-97107987-9 Tank Asm; Oil,ps 助力泵油壶 NKR/NPR/4HK1
			
8-97306217-1 Brake Oil Tank (power oil) 助力泵油壶 NPR/700P	8-97107987-0 Brake Oil Tank (power oil) 助力泵油壶 NKR/NPR/700P	8-94105282-1 Power Steering Oil Tank 方向机油壶 TFR/TFS/VCS	1-21210205-0 Power Steering Oil Tank 方向机油壶 FVR CXZ
			
8-97205136-0 Radiator Surge Tank 水箱稳压箱 NKR/NPR	1-21480104-0 Radiator Surge Tank 水箱稳压箱 FSR/FTR/FVR	8-97264247-0 Pipe; Suction 缸体进水管 TFR/TFS/4JB1	8-97209950-0 Turbocharger Hose (Return) 涡轮增压器软管(回水) TRR/NPR/700P
			
8-97063052-0 Hose; Vac Pump Return 真空泵回油管 TFR/TFS/4JB1/4KH1	8-98183778-0 Hose; Air Int 中冷器出水管 NKR/4JB1/4HK1	8-97260314-0 Hose, Rad 水箱中冷器软管 NKR/4KH1	8-98039933-1 Duct; Air 中冷器气管 700P/4HK1

ISUZU

			
8-94390035-0 Hose; Rad 水箱中冷器软管 FVR34/6HK1	8-94390043-0 Hose; Rad 水箱中冷器软管 FVR/6HK1T	8-98117928-2 Hose; Air Int 中冷器出水管 NPR/4HK1	8-98212435-0 Hose 中冷器进水管 NKR/4JB1
			
8-98281174-1 Hose; Conn 增压器进气管 NPR/4HK1	8-98183777-0 Hose; Air Int 中冷器出水管 NKR/NPR/4HK1	8-98012935-1 Hose; Rad 中冷器进水管 FVR/6HK1	8-97168373-0 Hose; Conn,acl 涡轮增压器进气管 NKR55/4JB1
			
8-97357625-0 Hose; Turbo 涡轮增压器软管 NKR55/4JB1-T	8-94150486-0 Belt Pulley 空调皮带轮 TFR/4ZE1	8-94334873-0 Pulley Asm; Idler 空调皮带轮 NPR/4HK1	8100070-850 Belt Pulley 空调皮带轮 NKR/4KH1-TC
			
8-94399957-0 Pulley Asm; Idler 空调皮带轮 FVR/6HK1	8-98031811-0 Idler Pulley 风扇皮带轮 NPR/FRR/4HK1	8-97161198-1 Air Conditioning Pulley 空调皮带轮 FTR/700P	1-19500643-0 Power Steering Pump 方向机助力泵总成 NPR/FTR/4HK1



3407010-L50PA
Power Steering Pump
方向机助力泵总成
NKR/4KH1



1-53215227-0
Rubber; Eng Foot
发动机脚胶
CXZ/CYZ/6WG1



8-97066799-0
Rubber; Eng Foot
发动机脚胶
TFR 4JB1



8-97066800-0
Engine Mount
发动机脚胶RH
TFR/4ZE1



1217230661
Core Asm; Oil Cooler
机油冷却器芯
FVR/6HK1



8943926200
Cooler Asm; Oil
机油冷却器总成
FSR/6HE1



8971690370
Cooler Asm; Oil
机油冷却器总成
TFR/TFS



8972239550
Oil Pan
油底壳
NKR/4JB1/4KH1



8-97039189-0
Rubber; Eng Foot
发动机脚胶
TFR55/4JB1



8-97086076-1
Engine Mount
发动机脚胶LH
TFR55/4JB1



8-97122893-0
Rubber; Eng Foot
发动机脚胶
NKR 4KH1



8-97122895-0
Rubber; Eng Foot
发动机脚胶
NKR/4KH1



8972399781
Cooler Asm; Oil
机油冷却器总成
NKR



8972523413
Fuel Pump
喷油泵
NKR/4KH1-TC



8972550691
MOTOR ASM; ENG STOP
发动机熄火装置
NPR/NQR/4HG1



8972550720
Motor Asm; Eng Stop
发动机熄火装置
NPR/4HE1



8-97080620-0 8-97080621-0
Engine Mount
发动机脚胶
NKR55/4JB1



8-97101826-0
Front Engine Foot Rubber LH
发动机脚胶
NPR/NQR



8-98061232-0
Engine Mount
发动机脚胶RH
FTR/700P/4HK1



8-97387250-2
Rubber; Eng Foot
发动机脚胶
FTR/700P/4HK1



8973865571
Pump Asm; Inj
喷油泵
NPR/4HK1



8974345731
Pump Asm; Inj
喷油泵
GIGA 6WG1



8974358404
Cylinder head cover
气门室盖
TFS/TFR/RZ4E



8976085730
Core Asm; Oil Cooler
机油冷却器芯
CXZ/CYZ/6UZ1



8-98013022-0
Rubber; Eng Foot
发动机脚胶
FVR/6HK1




8-98055380-0
Rubber; Eng Foot
发动机脚胶
CXZ/6UZ1



8-98055382-0
Engine Mounting Cushion Rubber
发动机脚胶(后) LH
FXR/GXZ/VC



1-53215147-0
Rubber; Eng Foot
发动机脚胶
CXZ/6WG1/6WF1



8980554790
Con-rod Bearing
连杆瓦
NPR/NQR/FVR/FTR



8-98018462-0
Nozzle Holder Sleeve
喷油嘴衬套
FVR/700P



8982511750
Cooler Asm Oil
机油冷却器总成
TFS/TFR



8987124731
Core Asm; Oil Cooler
机油冷却器芯
TFS/DMAX/4JJ1/4JK1



02 变速箱 TRANSMISSION PARTS



MY5T Gearbox
变速箱总成
MY5T



Transmission Asm; Manual
变速箱总成
MY6S



1701010-117C
Transmission Asm; Manual
变速箱总成
MLD6Q



MSB-5S
Transmission Asm; Manual
变速箱总成
NKR/4KH1



8-97844455-0
Transfer Asm
分动箱总成
TFS/UCS



Transfer Asm
分动箱总成
TFS/UCS



8980200252
Transmission Rear Cover
变速箱后壳
NPR/NQR/700P



8973793741
Case Trans
变速箱壳
NPR/NQR/700P



8-98240993-2
Box Asm; Shift Cont
变速箱上盖
NMR/NQR/M600/4KH1



8972526250
Trans Case
变速箱侧盖
PTO/NPR/NQR/700P/COVER/SIDE



8972526260
Cover; Case
变速箱侧盖RI
NPR/NQR/700P



8972370995
Flywheel Housing
飞轮壳
NPR/NQR/700P



8-97431272-0
Clutch Disc
离合器片
P430/VC46/6UZ1/6WA1



1-31240-980-0
Clutch Disc
离合器片430X10
CXZ



31250-E0780
Clutch Disc
离合器片
HINO



8-97432220-0
Clutch Disc
离合器片
VC61/6UZ1



31250-2400
Clutch Disc
离合器片
HINO



31250-2920
Clutch Disc
离合器片
HINO



31250-4990
Clutch Disc
离合器片
HINO



8-97432221-0
Clutch Disc
离合器片
VC61/6WG1



8-97431272-0
Clutch disc ISD212
离合器片 (430x10)
CYH/EYZ/VC



31250-6480
Clutch Disc
离合器片
HINO



31250-37320
Clutch Disc
离合器片
HINO



HND008-ISD015
Clutch Disc
离合器片
HINO



HND013
Clutch Disc
离合器片
HINO



HND058U
Clutch Disc
离合器片
HINO



HND013
Clutch Disc
离合器片
MITOBSHI



MFD009
Clutch Disc
离合器片
MITOBSHI



ISUZU



MFD013
Clutch Disc
离合器片
MITUBSHI




MFD015
Clutch Disc
离合器片
MITUBSHI



MFD037U
Clutch Disc
离合器片
MITUBSHI



5-87610049-2
Clutch Disc
离合器片
M100/600P/4KH1



1601060-LP20A
Clutch Disc
离合器片
NKR/NMR/NPR/M100/4HK1/4JB1/4HF1



1601010-150
Clutch Disc
离合器片 D=350
FRR/FSS/FTR/FVR/6HK1/4HK1



8-97367795-1
Clutch Disc
离合器片
700P/NP/RNQR/4HK1



8-97310796-0
Plate Asm; Pressure, CLU
离合器压板(D=300)
NKR/NMR/NPR/M100/4KB1/4HK1/4KH1



5-87610104-0
Clutch Pressure Plate D=325
离合器压板
NPR/NAR/700P



5-87610079-0
Clutch Pressure Plate D=300
离合器压板 D=300mm
NKR/NMR/NPR/M60



HNC-532
Clutch Pressure Plate
离合器压板
HINO



HNC549
Clutch Pressure Plate
离合器压板
HINO



HNC509
Clutch Pressure Plate
离合器压板
HINO



HNC517
Clutch Pressure Plate
离合器压板
HINO



ISC-549
Clutch Pressure Plate
离合器压板
HINO



8-94259132-0
Plate Asm; Pressure, CLU
离合器压板 D=240
NKR4JB1



1601040-D37TH
Bearing; Clu Release
离合器压板
VC66/6WG1



1601040-FEZ64
Clutch Pressure Plate
离合器压板(D=380)
FVR34/6HK1/6SD1



31210-1064
Clutch Pressure Plate
离合器压板
HINO



TYC526
Clutch Pressure Plate
离合器压板
HINO



8-97431273-0
Plate Asm; Pressure, CLU
离合器压板
VC46/6UZ1



8-97432218-0
Plate Asm; Pressure, CLU
离合器压板
VC61/6UZ1



5-87610110-0
Clutch Release Bearing
分离轴承
ELF/NKR/NPR/M100



85CT5740F3-1
Bearing; Clu Release
分离轴承
FVR34/6HK1



1601050-D17YZ
Bearing; Clu Release
分离轴承
VC61/6WG1/6UZ1



8-79255313-0
Block; Shift, CLU
分离轴承
NKR/NPR/4KH1



8-97316591-2
Bearing; Clu Release
分离轴承
TFR/UCS/DMAX/4JB1/4ZE1/4JK1;



8-97316602-2
Block; Shift, CLU
分离轴承
NKR/4JB1



8-97431274-0
Block; Shift, CLU
分离轴承
VC46/6UZ1



1-31310012-1
Clutch Release Bearing
分离轴承
FRR/NPR/ELF



1601050-D37TH
Bearing; Clu Release
分离轴承
VC66/6WG1



1-09820117-1
Bearing;
分离轴承
CLU/RELEASE/FVR34/FTR/6HK1/4HK1

ISUZU



5-87610207-0
Clutch Kit D=250
离合器套件 (D=250)
NKR/NPR/NQR



Fuso Clutch Kits
离合器套件



8-97033701-0
Clutch Fork
离合器拨叉
NKR/NLR/NRP/QKR



8-97310456-1
Clutch Fork
离合器拨叉
NPR/NNR/NQR/ELF



5-09812062-0
Clutch Release Bearing
分离轴承
NKR/NPR



1-31800383-0
Clutch Booster
离合器助力器
FVR/FTR/700P



8-98117644-1
Clutch Master Cylinder Assembly
离合器总泵
NKR/NPR/NLR



8-98117642-0
Clutch Master Cylinder Assembly
离合器总泵
NNR/NPR/700P



1-47500250-2
Clutch Master Cylinder
离合器总泵
FSR/PRR/FVR



MB295340
Clutch Master Cylinder
离合器总泵
MITUBSHI



8-97210748-9
Cylinder Asm; Clutch Master
离合器总泵
NQR/4KH1



1-60425208-4
Cylinder Asm; Clutch Master
离合器总泵
Vc61/6UZ1-TC



8-98089676-0
Clutch Slave Cylinder
离合器分泵
NPR/700P



MC125304
Clutch Slave Cylinder
离合器分泵
MITUBSHI



ME600096
Clutch Slave Cylinder
离合器分泵
MITUBSHI



ME602994
Clutch Slave Cylinder
离合器分泵
MITUBSHI



MK429254
Clutch Master Cylinder
离合器总泵
MITUBSHI



MK429255
Clutch Master Cylinder
离合器总泵
MITUBSHI



8-97255303-0
Fork; Shift, CLU
离合器拨叉
NKR/NPR/NLR/M600



8-97255201-0
Cover; Check Hole, dust
离合器拨叉防尘套
NKR/NPR/NNR/M600



8-97358248-0
Clutch Switch
离合器开关
NKR/NPR/700P



8-97620841-0
Switch; CLU
离合器开关
VC61/6UZ1



1701310-VP05A
Driver; Coupling
变速箱凸缘Z=21
M100/M600/4KH1



8-94441572-1
Cushion, eng Mtg, rr
变速箱吊胶(后)
TFS/UCS



1700705-D17YZ
Filter
变速箱滤芯
Vc61/6WG1



1-09625497-0
Transmission Front Oil Seal
变速箱前油封
CXZ/FRR/FFR/700P



8-97138632-0
Switch; Transfer Indicator
分动箱开关
TFR/TFS/UCS



1-82440101-0
Neutral Switch
空档开关
CXZ/EXZ/FRR/700P



8-97072947-0
Oil Pressure Switch (With Wire)
倒挡开关
NKR/NPR77



1-82440083-2
Reverse Switch (gray)
倒挡开关 2P
CX2/FVR/700P/NPR



8-97138635-0
Switch; Rev Lamp
倒挡开关
TFR/TFS/UCS



8-97433840-0
Clip
支撑座卡簧
VC61/6WG1



ME012532
Flywheel
飞轮
MITUBSHI



13450-1310
Flywheel
飞轮
HINO



13450-1320
Flywheel
飞轮
HINO



13450-2830
Flywheel
飞轮
HINO



13450-2414
Flywheel
飞轮
HINO



Me521106
Clutch Pressure Plate
离合器压板
MITUBSHI



ME431275
Flywheel
飞轮
MITUBSHI



ME431260
Flywheel
飞轮
MITUBSHI



8-97326227-0
Flywheel Assembly(Z=138)
飞轮1=138
NPR/NQR/700P



ME093092
Flywheel
飞轮
MITUBSHI



ME072584
Flywheel
飞轮
MITUBSHI



ME072248
Flywheel
飞轮
MITUBSHI



ME012551
Flywheel
飞轮
MITUBSHI



ME072102
Flywheel
飞轮
MITUBSHI



8-97046366-0
Flywheel Ring Z=138
飞轮齿环Z=138
NKR/NPR/700P



8-94419602-0
Gear; Ring
飞轮齿环Z=108
NKR/TFR55/4JB1



Mc056808 Mc056809
Ball Joint Tie Rod End
拉线球头



MC056810
Ball Joint Tie Rod End
拉线球头



8-97253124-0
Bushing; Driven Gear, speedometer
咪表齿座
NKR/NPR/FRR/ELF/4KH1



8-97253125-0
Bushing; Driven Gear, speedometer
咪表齿座
NKR/NPR/FRR/ELF/4KH1



8-97253561-1
Gear; Driven, SPD
咪表齿Z=14
NKR/NPR/ELF/M600/4KH1



8-97328058-2
Speed Sensor
咪表传感器
CXZ/EXZ/NPR/700P



1701094-P301
Gear; Driven, SPD
咪表齿Z=15
FVR34/700P/6HK1/4HK1



8-94473308-1
Gear; Driven, SPD
咪表齿Z=16
TFS/UCS/4JB1/4ZE1



8973280580
Sensor; Vehicle SPD
传感器(咪表)
FVR34/FTR/700P/6HK1/4HK1



1701110-VP05A
Sleeve & Hub Asm
同步器
M100/M600/4KH1



8-97366526-2
Sleeve & Hub Asm; 6TH
六档同步器
M100/M600/4KH1



1701220-VP05A
Sleeve & Hub Asm
同步器
M100/M600/4KH1



1701210-VP06A
Gear; 3RD, mainshaft
主档三档齿
M100/M600/4KH1



8-97386582-0
Gear; 6TH, mainshaft
主档六档齿
NPR/NQR/NNR/M600/4KH1



1701250-VP06A
Gear; 4TH, mainshaft
主档四档齿
M100/M600/4KH1



8-97253113-1
Bearing; Needle, 6TH, counter
副轴六档齿滚针轴承
M100/M600/4KH1



ISUZU



8-97241306-1
Gear Ring
同步齿环
NPR/NMR/FSR



8-97309532-0
Ring; Block, TOP & 4TH, OD
齿环4.5.6档
NPR/NLR/NJR/M600/4KH1



1-33265409-0
Gear Ring
同步齿环
NPR/NQR/FSR/FTR



8-97074619-0
Gear Ring (1/2)
同步齿环 (1/2)
NKR/NPR/FVR/200P



1332656192
Synchronizer
同步齿环
NPR/FVR



8971653170
Shaft; Output
分动箱中间轴
TFS



8971661570
Shaft; Output;
分动箱输出轴
TFS



8972041101
Gear; Counter
副轴
NKR



1702116-D17YZ
Cable; Shift, trans Cont
手选挡线 (换挡)
VC61/6WG1



2400230-T60PS
Actuator; Axle
电动拨叉
TFR/4KH1



8-98140853-0
Actuator; Axle
电动拨叉
TFR/4KH1



1803120-46
Arm; Shift
分动箱拨叉
TFS/UCS/4JB1/6VD1/4KH1



1313400770
Clutch Fork
离合器拨叉
NPR/FVR/FTR



8973104561
Fork; Shift, clu
离合器拨叉
NPR



8973104350
Shaft; Clu
离合器拨叉轴
NPR/FVR



1313421690
Shaft Clutch
离合器拨叉轴
NPR/FVR



8-98119293-0
Rod; Gear Shift, 6TH SUB
拨叉轴
NPR/FRR/M600/4KH1



1701352-VP05A
Rod; Gear Shift
六档拨叉轴承
M00/M600/4KH1



1701060-VP05A
Main Shaft
一轴
M100/M600/4KH1



8-97241325-1
Arm; Shift, 6TH
六档拨叉
NKR/NPR/NMR/M600/4KH1



1313211140
Clutch Release Bearing
离合器分离轴承座
NPR FTR FVR



1331312420
Rear Cover; Trans
变速箱后盖
NPR



8971046761
Cover; Frt, trans Case
一轴盖
TFR/TFS



8941118991
Rubber; Cushion, eng Mtg
变速箱吊架
NKR



1701630-VP05A
Needle Roller Bearing
一轴滚针轴承
M100/M600/4KH1



1701244-VP05A
Gear; Counter
副轴
M100/M600/4KH1



8-97045932-0
Shaft; Main, trans NKR
主轴
4JB1/4KH1



8-98019536-0
Detent; Ball
螺栓
NPR/FTR/4KH1



8974325420
Change Lever
换挡杆总成
GIGA



8972045058
Bracket; Change Lever
换挡杆总成 (六套件)
NHR/NKR/NMR/NPR/NQR



8-97204505-9
Bracket; Change Lever
换挡杆三件套
NKR/NMR/NPR/4JB1/4KH1/4HF1



1703030-T60PA
Bracket; Change Lever
换挡杆总成
TFS/4KH1

ISUZU



03 底盘系统 CHASSIS PARTS



9-00093130-0
Differential Cage Bearing
差速器侧齿轴承
FRR/NPQ/700P



8-97047296-0
Pinion Pilot Bearing(front)
差速器轴承(前)
FRR/NQR/NLR/700P



8-97107548-0
Differential Bearing (front)
差速器轴承(前)
WKR55



5-09812062-0
Differential Bearing (rear)
差速器轴承(后)
NKR/NPR/700P



8-94400890-0
CAGE; FINAL PINION
隔套(差速器轴承)
NKR/4JB1/4KH1



1-09812026-0
Bearing; Final Pinion
差速器轴承(后)
NPR/NKR/4HK1/4JB1



8-97107548-0
Bearing; Pinion Pilot
差速器轴承(前)
NKR/4JB1



9-00093602-0
Bearing; Diff Cage
差速器轴承(侧齿)
NKR/4KH1



1-09812142-0
Bearing; Hub Inner, Frt Axle
前轮轴承
FVR34/6HK1



1-09829043-0
Bearing;
轴承(转向节平面)
THRUST/KING/PIN/Vc46/FTR/6UZ1/4HK1



32008
Bearing; Hub Outer, frt Axle
前轮轴承(外)
TFS/UCS/4JB1/4ZE1



5-00093172-0
Bearing; Hub Inner, frt Axle
前轮轴承(内)
700P/4JB1/4HK1



5-00093149-0
Bearing; Hub Inner, frt Axle
前轮轴承(内)
700P/4JB1/4HK1



8-97122938-0
Bearing; Hub Inner, rr Axle
后轮轴承
NPR/4HK1



5-00032209-0
Bearing; Hub
后轮轴承
TFR/4JA1



9-00093082-0
Rear Axle Hub Outer Bearing
后轮轴承(外)
NPR/NQR/700P



9-00093081-0
Rear Axle Hub Inner Bearing
后轮轴承(内)
FKR/VPR/NMR



1-09812232-0
Rear Wheel Bearing (Outer)
后轮轴承(外)
CXZ/FRR/FVR



1-09812233-0
Rear Wheel Bearing (inner)
后轮轴承(内)
FRR/FVR/700P



9-00093607-0
Rear Wheel Bearing (outer)
后轮轴承(外)
NPR/700P



8-97122938-0
Rear wheel bearing (inner)
后轮轴承(内)
NPR/700P



8-94407708-1
Bearing; Knuckle
轴向往节轴承
TFR/TFS/UCS/4JB1/4ZE1/6VD1 4KH1



8-94407724-0
Bearing; Axle Shaft, inner
前轮轴承(内)
TFS/UCS/4JB1/4ZE1/4KH1



8-94227041-0
Bearing; Hub Outer, rr Axle
前轮轴承(外)
TFS/UCS/4JB1/4ZE1



8-94258819-0
Bearing; Hub Inner, frt Axle
前轮轴承(内)
TFS/UCS/4ZE1/4JB1/4KH1



8-94318527-2
Coupling; Final Drive Pinion
差速器凸缘(前)Z=13
TFS/UCS/4ZE1/6VD1



5-41227001-0
Retainer; Pilot Brg, pinion
差速器轴承保持架
NKR/4KH1



9-41219603-1
COLLAR; DIST, COLLAPSIBLE
隔套(差速器轴承)
NKR/4JB1/4KH1



ISUZU



8-94410338-0
差速器轴承座垫片
NKR/4KH1/4JB1



9-41227601-0
Retainer; Pilot Brg, pinion
差速器轴承保持架
NKR/4JB1T



1-41521035-2 1-41552020-0
1-41551024-0 8-97362599-0
Pinion Gear Sets
差速器齿轮修理包
FRR/NNR/700P



8-94247356-1
Washer; Lk, frt Hub Brg
前轮轴承锁止垫片
700P/NKR/4HK1/4JB1



8-97122937-0
Rear Wheel Oil Seal (Inner)
后轮油封(内)
NPR/700P



8-94336317-0
Rear Wheel Oil Seal (Outer)
后轮油封(外)
NPR/700P



1-09625041-0
Seal; Oil, frt Hub
前轮油封
FVR/6HK1/6UZ1




1-09625350-1
Seal; Oil, rr Hub, inner
后轮油封(内)
FVR/VC46/VC61/6HK1/6UZ1



8-94407718-0
Washer; Thrust, knuckle
转向节轴承锁止垫片
TFS/4JB1



1-09533012-1
Washer; Lk, frt Hub
前轮轴承锁止垫片
FVR34/VC46/VC61/6HK1/6UZ1



8-94247357-1
Frt Hub Brg
前轮轴承锁止螺母
NPR/4HK1/NUT



1-09840012-5
Nut; Frt Hub Brg
前轮轴承锁止螺母
FVR34/VC46/VC61/6HK1/6UZ1



8-94336314-0
Seal; Oil, rr Hub, inner
后轮油封(内)
NKR/4JB1



8-97373555-0
Seal; Oil, axle Shaft, inner
半轴油封(前内)
TFS/UCS/4JB1/4ZE1



1-09625444-0
Seal; Oil, rr Hub, outer
后轮油封(外)
FVR/VC46/VC61/6HK1/6UZ1



8-94426783-2
Coupling; Driving Pinion
差速器凸缘Z=18
NKR/4JB1/4KH1



8-97137094-0
Rear Hub Bearing Nut
后轮轴承螺母
NPR/700P



8-94442399-9
Nut; Adj, frt Hub
前轮轴承锁止修理包
TFS/UCS/4JB1/4ZE1




1-09625322-0
Final Pinion Oil Seal
差速器油封
CXZ/EXD/FVR



1-09625323-1
Differential Oil Seal (Middle Axle)
差速器油封(中桥)
CYZ/FVZ/VC



8-97075216-0
Coupling; Driving Pinion
差速器凸缘Z=17
NPR/4JB1/4ZE1/4BC2/4BE1



9-37249601-0
Cover
差速器凸缘防尘盖
NKR/4JB1/4KH1



8-94329526-1
Driving Pinion
锁止螺母(差速器凸缘)
NKR/4JB1/NUT



8-97226762-0
Gear; Pinion, Diff
差速器行星齿(后)Z=10
NKR/NPR/4JB1



8-94318520-0
Seal; Oil, final Pinion
前差速器油封
TFS/UCS/4ZE1/6VD1



8-94408083-0
Seal; Oil, final Pinion
差速器油封
NKR55/4JB1/4KH1



1-09625484-0
Differential Oil Seal
差速器油封
CX2/FSR/700P



2301112-46 8-97123692-0
Seal; Dust, drive Shaft
前半轴油封
TFS/UCS/4JB1/4ZE1/4KH1



8-97356349-0
Gear; Pinion, diff
差速器行星齿Z=10
NKR/4JB1T



8-97362599-0
Gear; Diff, lsd
差速器侧齿Z=20
NKR/NPR/NQR/4JB1/4HG1/4HF1



1-41561093-0
Differential Side Gear Z=20
差速器侧齿(Z=20)
NRR/NPQ/700P




8-94472118-0
Collar; Dist, Collapsible
差速器角齿套(前)
TFS/UCS/4JB1/4ZE1

ISUZU



ISUZU



1-41562073-0
Side Gear Thrust Washer
差速器侧齿垫
FPR/NRR/700P



8-94435308-0
Cross, diff Pinion
差速器一字轴
TFR/4JB1/PIN



9-09878096-0
Pin; Lk, cross Pin
差速器一字轴肖
TFR/UCS/4JB1/4ZE1



9-41521044-0
Pin; cross, diff Pinion
差速器一字轴(前)
UCS/4ZE1/6VD1



8-94320494-0
Bushing
差速器一字轴套(后)
UCS/TFR/4JB1/4ZE1



5-41521008-0
Spider; Diff Cag
差速器十字轴
NKR/4JB1T



8-94363151-0
4JB14ZE16VD1, RR AXLE HOUSING
差速器外壳(前)庆铃
TFSUCS



9-41562601-1
Washer; Thrust, side Gear
差速器侧齿垫
NKR/4JB1/4KH1



1-47020716-0 1-47120714-0
Brake Pads
刹车片总成
FVR/6HK1



1-47020715-0 1-47120713-0
Brake Pads
刹车片总成
FVR/6HK1



1-47120618-0
Brake Shoe
刹车片总成
CXZ/6UZ1



1-47120619-0
Brake Shoe
刹车片总成
CXZ/6UZ1



8-98244794-0
Brake Pad Kits (Front)
前刹车片
NPR/NQR



8-98216922-1
Front Brake Pads Kit
刹车皮片
NKR/4KH1



8-94461155-5
Pad Kit; Caliper, disc Brake, frt
前刹车片
TFR/TFS/UCR/UCS/4JB1/4ZE1



8-98215811-1
Front Brake Pads Kit
前刹车片
NKR77/4KH1



1-47115405-0 1-47115406-0
Front Brake Lining
前刹车片
FVR/6HK1



1-47125435-1 1-47125436-1
Rear Brake Lining
后刹车片
FVR/6HK1



8-97035085-1
Brake Pads
刹车片
NKR/4KH1T



8-97188455-1
Brake Shoe Kit
刹车片
700P/4HK1



8-97035085-0
SHOE: BRK, FRT (front and rear)
刹车片(带铁蹄)
NKR/NPR



8-97113218-1
Shoe; Brk, rr
刹车片(后)
TFS/4KH1



8-97168631-1
Rotor; Disc Brk, frt
前刹车盘
NKR/4KH1



8-97387229-1
Rotor; Disc Brk, frt
前刹车盘
NKR/4KH1



8-94388016-0 8-944388015-0
Caliper; Frt Disc Brk
前刹车分泵总成
TFR/TFS/4JB1/4ZE1



8-97358878-0
Rear Brake Wheel Cylinder LH
后刹车分泵总成LH
NPR/NQR/700P



8-97358879-0
Rear Brake Wheel Cylinder RH(Rear)
后刹车分泵总成RH(后)
NPR/NQR/700P



8-97358881-0
Rear Brake Cylinder Assembly RH(front)
后刹车分泵总成RH(前)
NPR/NQR/700P



MC865370
Brake Drum
刹车鼓



MC807783
Brake Drum
刹车鼓



8-97188115-0
Brake Drum 6 Holes(front and rear)
刹车鼓(6孔)
NPR/NNR/700P



3502711-T60PR
Brake Drum
刹车鼓
TFS/4KH1

ISUZU



ISUZU



8-94173247-0 8-94173246-0
Cover; Dust, frt Brake
前刹车挡板
TFS/UCS/4ZE1/4JB1/4KH1



8-971115566-1
Cable; Parking Brk
手刹线
TFS/4ZE1/4JB1/4KH1



8-97111565-1
Cable; Parking Brk
手刹线(后)
TFS/4ZE1/4JB1/4KH1



1205104-FE24H
Sensor (exhaust temperature) red
排气温度传感器
FVR/VC/700P



8-94316190-0
Sub Fuel Tank Unit
油箱感应器
NKR/NPR/700P



8-97261872-0
Upper Torsion Bar
驾驶室扭力杆
NPR/NQR/700P



8-98219393-0
Sensor; Spd, frt Wheel
ABS传感器
NNR/NPR/4HF1/4HL1



8-98219394-0
Sensor; Spd, frt Wheel
ABS传感器
NNR/NPR/4HF1/4HL1



8-97102372-0
Exhaust Brake Valve
排气阀动阀
NKR/NPR/NQR



47420-MA70A
Brake Unit; Exh
排气制动阀
NISSAN



8-97431770-0
Exhaust Brake Mag Valve
(exhaust braking)
电磁阀
CYZ/VC



1-82563602-0
Exhaust-Brake Mag Va
(Exhaust Braking)
排气阀动电磁阀
FTR/FVR/700P



1-82563871-0
Valve; Mag
电磁阀(排气制动)
FVR/NPR/6HK1T



8-97433875-0
Valve; Mag, variable Swirl System
电磁阀
VC61/6WG1



8-97641594-0
Solenoid Valve
电磁阀
CYH/EXZ/FVZ/VC



8-97170158-0
Drag Link
直拉杆
NPR/NQR



MC063089
Drag Link
直拉杆



MC090448
Drag Link
直拉杆



Mk382603
Drag Link
直拉杆



8-98006794-0
Drag Link
直拉杆



8-94389222-0
Drag Link
横拉杆
TFS/4JB1



8-94433680-1
Spring; Torsion Bar
驾驶室扭力杆
TFR/4JB1/4ZE1/4KH1



8-97125377-0 8-94259857-0 8-94407451-0
Clamp; Batte Rod; tension, battery
电瓶压板 电瓶拉杆
TFR/TFS/UCS/4ZE1/4JB1



3003010-T60PR
Tie Rod End
拉杆球头
TFR/4KH1



3103042-861
Wheel Nut (front) RH
轮胎螺丝(前)
NKR/NQR



8-97081585-0
Wheel Nut (rear) LH
轮胎螺丝(后) LH
NPR/700P



3103042-P302
Wheel Nut (front) RH
轮胎螺丝(前) RH
NPR/700P




8-98316702-0
Wrench; wheel PIN, 4119
轮胎套筒
NKR/4JB1



8-94173359-1
Fulcrum, frt Suspension
下悬挂臂轴螺丝
TFR/4JA1/PIN/



8-94408853-9
Stab Bar To Cont Arm
平衡杆座螺丝
UCS/4ZE1/BOLT



8-94437212-0
Pin; fulcrum, lwr Link
下悬挂臂轴螺丝
UCS/TFS/4ZE1/4JB1/4KH1



8-97307297-0
Bolt; Torsion Bar, height Cont
扭力杆座套螺丝
TFS/UCS/4JB1/4ZE1/4KH1

ISUZU



8-94459461-0 8-94459460-0
Arm; Lwr Cont
下悬挂臂
TFR/UCR/4JB1/4KH1/ARM



8-94367913-0 8-94367912-0
Arm; Lwr Cont
下悬挂臂
TFS/4KH1



8-97945844-1 8-97945843-1
Lower Control Arm
下悬挂臂总成
TFS/UCS/4KH1/4JJ1/4JK1



8-97945841-2 8-97945842-2
Upper Control Arm
上悬挂臂
TFS/UCS/4KH1/4JJ1/4JK1



8-944322752-0 8-944322751-0
Upper Control Arm
上悬挂臂
TFR/UCS/4JB1/4KH1



8-94322754-0 8-94322753-0
Upper Control Arm
上悬挂臂
TFS/UCS/4JB1/4ZE1/4KH1



8-94408841-0
Bushing; Lwr Link
下悬挂轴衬套
TFS/UCS/4JB1/4ZE1



8-97018166-0
Bushing; Lwr Link
下悬挂轴衬套
TFS/UCS/4JB1/4ZE1



8-98304418-1
Cab Air Spring (Rear)
空气弹簧(后)
CVZ/EXD/VC



1-52110142-3
SPRING
空气弹簧总成
VC46/VC61/6UZ1



1-43150802-1
Rod End; Tie Rod
横拉杆球头
VC46/6UZ1



8-97142101-2
Rod End; Tie Rod
横拉杆球头
NKR/4KH1



MW033301
Ball Joint Tie Rod End
横拉杆球头



MW033302
Ball Joint Tie Rod End
横拉杆球头



MR420082
Ball Joint Tie Rod End
横拉杆球头



MR420083
Ball Joint Tie Rod End
横拉杆球头



1-43150802-0 1-43150801-0
Tie Rod End L/R
横拉杆球头LHRH
FVR/FVM



8-94360802-1
Arm; Height Cont
扭力杆座(后)
TFS/UCS/4ZE1/4JB1/4KH1



8-94367757-0 8-97032976-1
Seat; Torsion Bar, height Cont
扭力杆螺座
TFS/UCS/4JB1/4ZE1/4KH1



8-94435413-0
Arm; Lwr Link
扭力杆座
TFS/4JB1



8-97160094-0
Rear Shock Absorber
后减震器
NKR/NPR/NQR



8-97107985-0
Front Shock Absorber
前减震器
NKR/NPR



1-51630602-0
Rear Shock Absorber
后减震器
EXR/GXR/VC



8-98080129-1
Front Shock Absorber
前减震器
NPR/NQR/700P



8-94312814-0
Steering Damper
横拉杆减震机
TFR/UCS/4JA1



8-97253651-0
Absorber Asm; Shock, rr Susp
后减震机
NKR/4JB1



8-97107985-1
Absorber Asm; Shock, frt
前减震机
NKR/4JB1




8-98304422-0
Absorber Asm; Shock, rr Mtg
后减震机
VC61/6WG1



1-51381022-1
Trunnion, rr Susp
后平衡轴总成
VC46/FVZ6UZ1/6HK1/SHAFT



1-51389058-0
Air tank Asm
平衡轴托架衬套
CXZ/FVZ/VC



8-98081832-0
Trunnion Shaft Bushing
平衡轴托架衬套
CVZ/FVZ/VC



1-48210278-5
Air Relay Valve
继动阀
CXZ/EXZ/FVR



8-94171274-0
Bushing; Leaf Spr,rr
后钢板胶套
TFR/4JB1/4KH1



8-97034380-0
Leaf Spring Bushing
后钢板封套
NKR/NPR/700P



8-94113323-0
Rear Spring Shackle Bushing
后钢板胶套
NKR/NPR/NQR



8-94234319-1
Bushing; Shackle,rr Spr
后钢板胶套
TFR/TFS/UCS/4JB1/4ZE1



8-97532751-0
Booster; Hydraulic Brk
刹车助力器总成
700P/4HK1



5-87830978-2
Steering Knuckle Repair Kit
转向节修理包
NKR/NPR/700P



5-87830978-2
King Pin Kit
转向节修理包
NKR/700P/4JB1/4KH1/4HK1;



8-94376223-1
Gear Set; Final Drive,frt
盘角齿组件(前)
TFS/UCS/4JB1/4ZE1/6VD1



8-94318777-1
Bushing; Rubber,stab Bar
平衡杆胶套
TFS/4JB1/4JA1



8-94173374-0
Bumper; Rubber,strut
下悬挂臂缓冲胶
TFS/4JB1



8-94433673-0
Bumper; Rubber,strut
下悬挂臂缓冲胶
TFR/4JB1/4ZE1/4KH1



8-97362962-0
Rubber; Rebound,strut
上悬挂臂缓冲胶
TFS/TFR/4JB1/4ZE1/4KH1



8-98020789-0
Journal Asm; Prop Shaft
传动轴十字头
700P/4HK1



8-37300601-0
Journal Asm; Prop Shaft
传动轴十字头
TFR/UCS/4JB1/4ZE1



1-37300102-0
Propeller Shaft Journal Assy
十字节
CXZ/FVZ/FRR



8-97035455-0
Final Drive Gear Set 7;43
盆角齿组件(7:18)
NKR/NPR/NQR



8-94173375-A
Bumper; Rubber,strut
下悬挂臂缓冲胶
TFS/UCS/4JB1/4ZE1/4KH1



8-94118510-0
Cushion Rubber
后钢板缓冲胶
NKR/NPR/NQR



8-97086442-0
Cab Mounting Rubber(rear)
驾驶室缓冲胶
NKR/NPR/700P



8-94119958-1
Sub Spring Rubber
副钢板缓冲胶垫
NKR/NPR/NQR/700P



8-97235776-0
End Asm; Frt Axle
转向下球头
TFS/D-MAX/4JB1



8-97235776-0
Joint Asm; Ball,lwr Cont Arm
转向下球头
TFS/UCS/DMAX/4JB1/4ZE1



8-98110220-0
Steering Unit
方向机总成
700P/M100/NIKA/4HK1



8-97101354-1
Steering Unit
方向机总成(液压)
TFR/UCS/4JB1/4ZE1



9-09653002-0
Bearing Nut Lock Washer
半轴锁止垫片
FRR/NPR/700P



1-51389018-1
Key,shaft
后平衡轴锁销
FVZ/VC46/VC61/6HK1/BOLT



8-94438334-1
Pin; Rr Spr
后钢板肖
TFR/UCS/4JB1/4ZE1/4KH1



8-94469777-0
Shim; Brg Holder
后轮古座垫片
TFR/TFS/4JB1/4KH1



3411100-T60PR
Steering Unit
方向机总成
TFR/4KH1



8-98208757-0
Valve; Leveling,frt Susp
高度阀(前)
VC46/VC61/6UZ1



8-94378401-0
Hand Brake Disc Assembly
手刹盘总成
NKR/NRR



8-97028610-0
Rubber; Frt,mud Guard
挡泥板胶皮(前)
TFR/4JB1



ISUZU



8-97102823-1
Lever Asm; Relay, strg Linkage
副帮肋
TFR/TFS/4JA1/4JB1




8-94455238-0
Clamp; Lwr, rr Spr
后减震机托架
TFR/4JB1/4KH1



8-94143209-0
Bracket; Stab Bar To Frame
平衡杆吊架
TFR/TFS/UCS/4JB1/4ZE1/4KH1



894450311-0
Shackle; Rr Spr
后钢板吊耳
TFR/4JA1



8-97134439-0
Axle Shaft(Z=20)
半轴(Z=20)
NPR/NQR/700P



9-09855207-0
Axle Shaft Special Washer
半轴螺母介子
FKR/NPQ/700P



5-09300066-0
Axle Shaft To Hub Stud
半轴螺丝
NKR/TFR



8-97113447-0
Cover Sub Asm; Free Wheel Hub
轴头离合器
TFS/UCS/4JB1/4ZE1/4KH1



8-94381084-1
Hub; Frt Axle
前轮芯
TFS/UCS/4JB1/4ZE1/4KH1



8-97101414-0
Wheel Hub Bearing
前轮芯
NPR/700P



8-97304117-1
Brg Holder
后轮古座
TFR/UCS/4JB1/4ZE1



3521321-142
Air Dryer
干燥罐
FTR/FVR/NPR/4HK1/6HK1



8-94328799-1
Bearing Asm; Ctr, prop Shaft
传动轴过桥
TFS/UCS/4ZE1/4JB1



8-94376303-4
Transmission Shaft
前驱动轴
TFS/UCS/4JB1/4ZE1



8-94341284-0
Spare Tire Rack
备胎架
NPR/NQR/700P



1375100943
Bearing; Center, prop Shaft
过桥轴承
CXZ/FVZ



1423152202
Brake drum RR
后刹车鼓
CXZ/CYZ/GIGA



1423153600
Brake drum RR
后刹车鼓
FRR/NRR



1423153650
Brake drum FR
前刹车鼓
CXZ/CYZ/GIGA



1476010870
Expander
刹车分泵扩张器
CYZ/CXZ



1476013810
Brake Cylinder
制动分泵
FSR



1476230359
SCREW; ADJ
扩张器调节螺栓
CYZ/CXZ/HINO



1481903680
Dryer; Air
前刹车鼓
CXZ/10PE1



1511620290
Shackle; Frt Susp
钢板吊耳
FTR/FRR/FVR



1533530781
Shackle; Frt Susp
后钢板吊耳
FVR/FTR/FRR



1533590470
Pad; Rr Spr
钢板吊耳垫
FTR/FRR



1533610650
Trunion Shaft bracket assy
后平衡轴托架总成
CYZ/CXZ/GIGA



8974338900
Dryer; Air
空气干燥器总成
FVR/GIGA



8979470973
Shock Absorber; FR
前减震机
TFS/TFR



8980799020
Leaf spring RR
后钢板总成
NPR



8980799230
Leaf spring FR
前钢板总成
NPR



8982290200
Adjuster Asm; Slack
刹车调节臂
NPR

ISUZU



1-48100872-0
Valve; Brk
刹车总泵总成
CYZ/EXZ/FTR/FVR



1-48250640-0 1-48250641-0
Chamber Asm; Spring
气室(后)LH RH
FVR/CXZ



1-51385091-0
Seat; Spr,lwr
平衡轴托架
FVZ/CXZ/CYZ/VC



1-53354064-1
Bracket; RR SPR,RR
后钢板支架(后)
FVZ/CXZ/VC



8-94164553-0
Nut; Prop Shaft
传动轴螺母 M10
NKR/NPR/TFS



8-97040629-0
STOPPER; SUB SPR
副钢板支架(后之后)
NKR/NPR



8-97388700-0
Drive Asm; Final,RR
后差速器10 41
NPR/NQR/700P



8-97947016-3
Shock Absorber; RR
后减振机
TFR/TFS/UCS



8-98020880-1
Bearing Asm; Ctr,prop Shaft
传动轴吊胶
NPR/NQR/700P



8-98032489-1
Bracket; RR SPR,RR
后钢板支架(后)RH
NPR/700P



8-98038384-0
Axle; Frt
前桥
NNR/NPR/ELF/700P



8-98043596-0
Chamber; Power
排气腔
NPR/NQR/NLR



8-98084602-0
Dpd Asm
催化器总成
NNR/NPR/FVR/700P



8-98201369-1
Cap; Fuel Tank
带锁油箱盖
NPR/NQR/FSR



Chassis Frame Assy
庆铃车架
TFR/TFS/NKR55/NKR77/NPR
NQR/700P/VC46/Vc61



2400010-P70PA
RR Chassis Assy
后桥总成(气刹)
700P

04 车身 BODY PARTS



Cabin Assy
驾驶室总成
GIGA



Cabin Assy
驾驶室总成
NPR/700P



Cabin Assy
驾驶室空壳
NPR/700P



Cabin Assy
单排驾驶室总成
NKR77



Double Cabin Assy
双排驾驶室总成
NKR77



Cabin Assy
双排驾驶室总成
NKR77



Chromed Parts
镀铬件改装
NKR/NPR



Chromed Parts
镀铬件改装
NPR/NQR



8-97585855-1
Front Panel Assembly(inner)
前面板总成(内)
NPR/700P



8-98021859-0
Front Panel Assembly
前面板总成L=135cm
NPR/NNR/700P



Front Bumper N/W
前保险杠
HINO



Rad Grille (Chrome)
前保险杠(镀铬)
NKR/NPR/GIGA



8-97472544-0
Front Grille
前中网
NPR/4HK1



8-97405581-3
Front Grille
前中网
NPR/4HK1T



1301110-PE25A1
Rad Grille
前中网 (L=133)
NPR/KV100/700P



8-97472544-0
Rad Grille(Chrome)L=133
前中网L=133cm
NPR/FTR/700P



1301112-PE25A
Front Grille
前中网
NPR/4HK1



Front Grille N/W
前中网
HINO



Front Grille N/W
前中网
HINO



8-98196820-4
Front Grille
前保险杠格栅
CXZ/CYZ/6WG1



8-98028086-0
Front Side Panel
镀铬包角
NKR/77/NPR/4HK1



1-65481591-0
Panel; Front,side
面板包角LH
FVR/FTR/6HK1



8-97581609-0
Front Side Panel
面板包角
NKR/NPR/4HK1



8-98028086-1
Front Side Panel
前沙板护角(凸) LH
NPR/NQR/700P



8-98273499-1
Bezel; Bumper
前大灯框
CXZ/CYZ/6WG1-T



8-98273498-0
Front headlight frame RH(chrome)
大灯框RH
CXZ/EXZ/VC



8-97468461-0
Support Asm; Step
上车踏板内衬板
GIGA/6WG1



1-71268429-1
Blister Fender
叶子板
FSR/FVM/FVR



8-97369571-3
Lamp Asm; Head
左前大灯总成LH
NKR/NPR



8-97369570-0
Front Headlight Assembly RH
前大灯总成RH
NKR/NPR



8-97557923-9 8-97557924-1
Head Lamp Assy
前大灯总成
ELF/NPR/FSR



8-98241317-0
Lamp Asm; Head
前大灯总成
ELF/NPR/FSR



8-98241324-0
Head Lamp
大灯总成LH RH
CXZ/NPR/700P



Headlamp RH/LH
前大灯总成LH/GH
HINO



Headlamp LH/RH
前大灯总成
HINO



Headlamp RH/LH
前大灯总成GH/LH
HINO



Corner Lamp LH/RH
前转向灯LH/RH
HINO



8-98155458-2
Lamp; Turn Signal
前转向灯总成
NPR/4HK1-TC



8-97585173-1
Lamp; Turn Signal
前转向灯LH
NPR/700P



8-98155459-0
Lamp; Turn Signal
前转向灯总成LH
NPR/FRR/700P



1-86830132-1
Lamp Asm; Frt Comb
前转向灯总成
FVR/6HK1



8-98155458-2
Lamp; Turn Signal
前转向灯总成
NKR/4KH1-TC



1-82110477-0
Lamp Asm; Rr Fog
雾灯总成
NPR/4HK1



8-97353955-2
Fog Lamp Assembly LH
雾灯总成LH
NPR/CXZ/EXZ/FVR



ISUZU

ISUZU

			
8-97378909-0 Fog Light LH 雾灯总成LH NPR/NLR/FRR	3732030-GEA00 Fog Light 雾灯总成 EVM100GEA	8-97410181-3 Lamp Asm; Side Turn Signal 前侧灯总成 NPR/4HK1	Door Flasher Wide RH/LH 车门侧灯RH/LH HINO
			
8-94178618-0 Rear lamp assembly RH 后灯总成RH NKR/QKR	Tail Lamp RH/LH 尾灯总成RH/LH HINO	4133020-D17YZ Rear Lamp Assembly RH LED 后灯总成(LED) RH Vc61	8-98013421-3 Lamp Asm; room 顶灯 NPR/700P/VC
			
8-97659898-0 Cover; Radar 前转向灯装饰盖 NPR/NQR/4HF1	8-97468549-0 Fender; Frt 前叶子板轮眉 GIGA/6WG1	8-97431226-0 Under Mirror (ground mirror) 照地镜 GXR/FVR/VC	8-98070493-0 Side Mirror LH 倒车镜LH NPR/700P
			
8202020-D17YZ Side Mirror Assy 倒车镜总成 CXZ/6WG1-T	8202310-D17YZ Under Mirror 补盲镜总成 CXZ/6WG1-T	8202820-P301 Under Mirror 倒车镜(照地镜) NPR/4HK1-T	8-98063785-2 Stay; Mirror Support 倒车镜支架支撑杆 NPR/CXZ/6UZ1-TC

			
8-97408065-1 Btool Box (roof) LH 车顶工具箱LH NPR/NQR/700P	8-97405261-0 Tool Box 工具箱 NPR/NNR	8-97406043-9 Lid; Fuse Box 仪表台电器盖 NPR/4HK1-T	Rear Pillar LH/RH 后柱饰板LH/RH HINO
			
8-97412556-0 Steering Wheel 方向盘 NPR/700P	8-98031802-2 Outside Mirror Cover RH(large) 倒车镜支架饰盖(RH) M600/700P/VC	8-97406003-0 Dashboard Side Panel 仪表盘侧板 NPR/NLR/700P	8-98031805-0 Outside Mirror Cover 倒车镜支架饰盖(RH) M600/700P/VC
			
Step Panel RH/LH 上车踏板RH/LH HINO	8-98022775-1 Step Asm; Rr 上车踏板总成LH NPR/4HK1-TCS	8-98030767-1 Fuse Box Cover (chassis) 保险丝盒盖 NPR/VC46/700P	8-98034018-8 Fuse Box (chassis) 保险丝盒 KV600/700P/VC
			
1-53414180-0 Step Plate 上车踏板(下) CXZ/CYZ/6UZ1-TC	8-98038293-0 Front Door Hinge 前门铰 NPR/FTR/700P	8-98029234-2 Regulator; Window, Door 前门玻璃升降器LH NPR/NQR/700P	8-98029237-2 Regulator; Window, frt Door 前门玻璃升降器 NPR/4HK1/6HK1



Truck Door Shell RH/LH
车门
HINO




8-97852115-0 8-97852116-0
Regulator; Window, frt Door
前门玻璃升降器
NKR/4JB1TC



8-98058429-0
Motor; Power Window Reg, frt Door
前门玻璃升降器电机
NPR/6UZ1/4HK1



8-98058429-0
Motor; Power Window Regulator
升降器马达
NPR/FXZ/700P/VC



8-97301793-1
Door Handle
摇手
NPR/700P



8-97585576-3
Tool Box Bracket RH
车顶工具箱支架RH
NPR/NLR/700P



8-97426944-1
Inner Handle
前门内拉手
FVR/6HK1T



8-97155249-1 8-97155246-0
Power Window Switch
电动车开关
TFR/4JB1



8-97155246-0
Switch; Power Window
电动窗开关
TFR/4JB1T



8-97098342-0 8-97098341-0
Switch; Power Window, rr
后门电动窗开关
TFR/4JA1



8-98316418-0
Power Window Switch
电动窗开关
FRR/FVR/NPR/ELF



1-82380158-3
Power Window Switch RH
电动窗开关RH
FSR/FRR/FVR



8-98159544-A
Switch; Power Window
电动窗开关
NPR/4HK1/6UZ1



8-97155246-0
Switch; Power Window
电动窗开关
TFR/4JB1



8-98017421-0
Lock; Door, frt Door
前门锁RH
CXZ/CYZ/6UZ1-TC



8-98017422-0
Lock; Door, frt Door
前门锁LH
CXZ/CYZ/6UZ1-TC



8-98021249-1
Meter Compl; Cluster
仪表总成
NPR/4HK1-TCS



8-98073850-0
Switch; Comb
组合开关
NPR/4HK1-TC



8-98073850-0
Combination Switch
组合开关
NPR/NQR/700P



8-97433549-0
Combination Switch
组合开关
VC61/6UZ1T



8-97833987-0
Relay (ECM) 5P
继电器 (ECM) 5P
NPR/FTR/CXZ/700P



8-97264947-0
Relay (start) 4P
越动继电器
NPR/FTR/700P



8100340-FE64R
Relay 5P
喇叭继电器
FVR/700P



1-83470060-0
Flasher Relay 5P
闪光继电器5P
CXZ/FVR/700P



8-97262933-0
Relay; HTR & AC
喇叭继电器
700P/4HK1T



8-98060789-0
Door Lock Relay 24V
继电器 (24VB)
FRR/EXD/VC



8-98005631-1
Starter Relay (flashing)
闪光继电器
YCZ/FRR/FVR/VC



8-97173947-0
Starter Relay 5p
预热继电器5P
CXZ/FRR/NPR/700P/VC



8-98032643-0
Radio
收音机总成
NPR/4HK1



8-97317001-0
Speaker; Audio
收音机喇叭
NPR/CXZ/4HK1/6UZ1



8-97329641-A
Lighter; Cigar
点烟器
TFR/TFS/4JA1



8-97320325-0
Lighter; Cigar
点烟器
NPR/FVR/4HK1/6HK1



1-80220023-1
Press Switch 3P
气压表传感器
NKR/M100/700P/VC



8-98010856-1
Switch Relay Valve (Air Pressure) 2.0 2P
气压开关2.0(2P)
CXZ/FUR/GUR



8-98010857-0
Pressure Switch (air pressure) 0.3 2P
气压开关0.3(2P)
CYZ/EXZ/FRR/VC



8-97609249-0
Pressure Switch (low pressure) 5.5 2P
低压开关5.5(2P)
CYZ/EXZ/FRR/VC



8-98025520-0
Condenser Assy
冷凝器
700P



8-98025520-0
Ac Condenser
冷凝器
NPR/4HK1-TCS



8-98090684-0
Blower Asm; Shroud
电子扇总成
NPR/4HK1



8-98116590-1
Blower Asm; Shroud
电子扇总成
CXZ/CYZ/6UZ1



8-97387036-1
Lock ASM;STRG
点头开关座
CXZ/NPR/VC46/700P



8-97170877-0
Ignition Switch
点火开关座总成
TFR/4JA1



8-97386922-1
Switch; Hazard
仪表开关(应急灯)8P
NPR/CXZ/FVR/GVR/NQR



1-53497486-0
Ashtray (front door) LH
烟灰缸LH
FSR/FVM/FVZ



8-98034145-3
Heater Unit
暖风机
NKR/NQR/FRR/ELF/700P/4HK1



8-98034146-1
Blower Unit
鼓风机
NPR 4HK1-TC



8-98047494-0
Radiator Heater Core
暖风水箱
NPR/700P



8-98183926-0
Motor Asm; Fan,blower Unit
鼓风机马达
NPR/4HK1



8-98029124-1
Wiper Motor
雨刷电机
700P



8-97078452-0
Resistor; Power Evap
鼓风机电阻5P
TFR/TFS/4JA1/4JB1



8-98077418-0
Blower Resistance
鼓风机电阻
FRR/NPR/700P



8-98047429-0
Amplifier; Heater Unit
温控开关
NPR/700P/4HK1



8-98006433-0
Pipe; HTR
暖风钢管
NPR/4HK1



1-83572381-0
Air-conditioning Pipe
冷气管
FVR/FTR/4HK1/6HK1



8-98006105-2
Hose; Flex,ac,evap To Cmpr
空调管
NPR/700P/KV600



8-98006103-1
Hose; Flex,ac
空调管
NPR/4HK1



8-98037146-1
Compressor Asm; Ac
冷气压缩机
NPR/FTR/4HK1-TCS



1-83543050-0
AC Control Assy
暖风开关
EXZ/CXZ/FVR



8-98067881-1
AC Switch
暖风开关
NLR/NQR/ELF



8101530-D17YZ
Heater Switch
暖风开关
CXZ/CYZ/6UZ1/6WG1



8-98006339-0
Bracket; Ac
冷凝器支架
NPR/4HK1-TCS



8-97049568-0
Tank Asm; Oil
刹车油壶
NKR/NPR/4JB1/4HF1



1-21481143-1
Sub Tank Asm
水箱稳压箱
FVR/FTR/VC



8-98029136-1
Tank; Washer
喷水壶总成
NPR 4HK1



8-98025185-3 8-98025184-3
Front Bumper Bracket
前保险杠支架
NPR/NQR/700P



8-98074800-0
Bracket; Cab Mtg, center
驾驶室支架胶
NPR/4HK1



8-98050434-1
Cover Asm; Acl
空气滤清器盖
NPR/NQR/NRR/4HK1/4HF1



5101978-D17YZ
Mudguard
挡泥板总成-后
CXZ/CYZ/6WG1-TC



3003011-T60PR
Tie Rod End
方向机横拉杆球头
TFR/4KH1CT5H1



3404100-T60PR1
Steering Core Unit
方向机芯总成
TFR/4KH1



3411100-T60PR
Steering Unit
方向机总成
TFR/4KH1CT5H1



8-97207518-0
Shaft; Strg
方向机芯总成
TFR/4JB1



8-97406375-3
Shaft Asm; Strg
方向机芯总成
NPR/4HK1T



8-97400061-0
Shaft Asm; Strg
方向机芯总成
NKR/4JB1



8-98123310-0
Stay Asm; Cab Tilt
驾驶室撑杆
NPR/4HK1



8-97152689-1 8-97152688-1
8-97152690-0,
Plate; Sill, frt
地板胶压条;卡扣
TFR/TFS/4JA1/4JB1



1-79998913-0
Gear Shifter Dust Cover(rubber)
换挡杆防尘罩(上)
FVR/700P



8-98022746-1
Fender LH
发动机挡泥板LH
NPR/NQR



8-98029199-3
Weatherstrip; Front Door
前门密封胶条
NPR/4HK1



8-98178803-0
Harness
车门线束
CXZ/6UZ1-TC



8-94291927-0
Clip
卡扣
NKR/NPR



8-97867240-0
Clip
卡扣
NKR/QKR



8-98021300-0
Clip
卡扣
CYZ/FRR/FVR/GVR/NPR



8-97853168-0
Clip
卡扣
NKR/QKR



8-97102415-0
Clip
卡扣
NKR/NPR



8-94279974-1
Clip
卡扣
NKR/QKR



8-97055001-0
Clip (front fender lining)
卡扣
NKR/QKR



8-97410741-0
Side Panel Clip
前沙板护角胶粒
NKR/4JB1CN



8-98021300-2
Grommet; Frt Panel
前沙板护角胶粒
NPR/4HK1



8-97581632-2
Clip; Frt Panel Side
前沙板护角胶粒
NKR/4KH1



8-98041913-0
Mark; Isuzu
标志 ISUZU
CXZ/CYZ/6UZ1-TC



3903321-D17YZ
Isuzu Label
标志 GIGA
CXZ/CYZ/6WG1-TC51



Dashboard Assy
仪表台总成
NPR/NQR/700P



8-97852634-0
Pad; Trim, Frt Door
前门内饰板RH
NKR/NPR



8-97211011-0
Cable Clip
卡扣
NKR/QKR



8-97011448-0
Cable Clip
卡扣
NKR/QKR



05 BVP catalog

行号	零部件号		数量
1	5876101291	Front Shock Absorber	BVP
2	5876101530	Front Shock Absorber	BVP
3	1876101550	Front Shock Absorber	BVP
4	1876101540	Front Shock Absorber	BVP
5	5876101560	RR Shock Absorber	BVP
6	5876101540	RR Shock Absorber	BVP
7	5876101261	Front Shock Absorber	BVP
8	1876101530	Front Shock Absorber	BVP
9	5876101330	RR Shock Absorber	BVP
10	5876101590	Front Shock Absorber	BVP
11	5876101320	RR Shock Absorber	BVP
12	1876101710	Central Bearing	BVP
13	1876101690	Central Bearing	BVP
14	5876102000	Central Bearing	BVP
15	5876102030	Central Bearing	BVP
16	5876102010	Central Bearing	BVP
17	1876101700	Central Bearing	BVP
18	5876102020	Central Bearing	BVP
19	1876101720	Central Bearing	BVP
20	5876101380	Inner Hub Bearing	BVP
21	5876101420	Inner Hub Bearing	BVP
22	1876101380	Inner Hub Bearing	BVP
23	5876101360	Outer Hub Bearing	BVP
24	5876101340	Outer Hub Bearing	BVP
25	5876101390	Outer Hub Bearing	BVP
26	5876101400	Outer Hub Bearing	BVP
27	1876101360	Outer Hub Bearing	BVP
28	1876101490	Clutch Release Bearing	BVP
29	1876101480	Clutch Release Bearing	BVP
30	5876101470	Clutch Release Bearing	BVP
31	5876101160	Clutch Release Bearing	BVP
32	5876101630	Leaf Spring Bushing	BVP
33	5876101620	Leaf Spring Bushing	BVP
34	5876101600	Leaf Spring Bushing	BVP
35	5876101610	Leaf Spring Bushing	BVP
36	1876101770	Trunion Shaft Bushing	BVP
37	1876101960	Clutch Disc	BVP
38	1876101420	Clutch Disc	BVP
39	1876101400	Clutch Disc	BVP
40	5876101250	Clutch Disc	BVP
41	1876101520	Fuel Filter	BVP

行号	零部件号		数量
42	1876101510	Air Filter	BVP
43	5876101480	Air Filter	BVP
44	5876101640	Pilot Bearing	BVP
45	1876101570	Pilot Shaft Bearing	BVP
46	1876101580	Pilot Shaft Bearing	BVP
47	5876101650	Pilot Shaft Bearing	BVP
48	5876101660	Pilot Shaft Bearing	BVP
49	1876101450	Clutch Pressure Plate	BVP
50	1876101460	Clutch Pressure Plate	BVP
51	1876101470	Clutch Pressure Plate	BVP
52	5876101440	Clutch Pressure Plate	BVP
53	1876101620	Engine Foot Rubber	BVP
54	5876101950	Engine Foot Rubber	BVP
55	5876101880	Engine Foot Rubber	BVP
56	5876101870	Engine Foot Rubber	BVP
57	5876101960	Engine Foot Rubber	BVP
58	5876101920	Engine Foot Rubber	BVP
59	5876101910	Engine Foot Rubber	BVP
60	5876101930	Engine Foot Rubber	BVP
61	5876101890	Engine Foot Rubber	BVP
62	5876101940	Engine Foot Rubber	BVP
63	5876101900	Engine Foot Rubber	BVP
64	1132402440	Fuel Filter	BVP
65	1874110742	Torque Rod Bush	BVP
66	1876100570	Oil Filter	BVP
67	1876100581	Air Filter	BVP
68	1876100590	Oil Filter	BVP
69	1876100720	Fan Belt	BVP
70	1876100750	A/C Compressor Fan Belt	BVP
71	1876100760	A/C Compressor Fan Belt	BVP
72	1876100770	A/C Compressor Fan Belt	BVP
73	1876100820	Torque Rod Bush	BVP
74	1876100933	Fuel Filter	BVP
75	1876100941	Fuel Filter	BVP
76	1876100942	Fuel Filter	BVP
77	1876101080	Clutch Release Bearing	BVP
78	1876101090	Clutch Release Bearing	BVP
79	1876101100	Clutch Release Bearing	BVP
80	1876101112	Air Filter	BVP
81	1876101122	Air Filter	BVP
82	1876101132	Air Filter	BVP

行号	零部件号		数量
83	1876101141	Air Filter	BVP
84	1876101152	Air Filter	BVP
85	1876101162	Air Filter	BVP
86	1876101170	Air Cleaner Filtler	BVP
87	1876101181	Air Cleaner Filtler	BVP
88	1876101190	Clutch Disc	BVP
89	1876101200	Clutch Pressure Plate	BVP
90	1876110000	Clutch Disc	BVP
91	1876110010	Clutch Pressure Plate	BVP
92	1876110020	Clutch Disc	BVP
93	1876110030	Clutch Pressure Plate	BVP
94	1876110040	Clutch Release Bearing	BVP
95	1876110050	Fuel Filter	BVP
96	1876110060	Oil Filter	BVP
97	1876110070	Oil Filter	BVP
98	5876100020	Clutch Disc	BVP
99	5876100041	Clutch Disc	BVP
100	5876100050	Clutch Disc	BVP
101	5876100060	Clutch Disc	BVP
102	5876100080	Oil Filter	BVP
103	5876100090	Oil Filter	BVP
104	5876100100	Oil Filter	BVP
105	5876100110	Fuel Filter	BVP
106	5876100120	Fuel Filter	BVP
107	5876100170	Oil Filter	BVP
108	5876100180	Air Cleaner Filtler	BVP
109	5876100201	Air Cleaner Filtler	BVP
110	5876100210	Oil Filter	BVP
111	5876100230	Oil Filter	BVP
112	5876100410	Fuel Filter	BVP
113	5876100492	Clutch Disc	BVP
114	5876100501	Clutch Pressure Plate	BVP
115	5876100520	Clutch Fan Belt	BVP
116	5876100540	A/C Compressor Fan Belt	BVP
117	5876100550	Fan Belt	BVP
118	5876100560	Fan Belt	BVP
119	5876100570	Fan Belt	BVP
120	5876100580	Fan Belt	BVP

行号	零部件号		数量
121	5876100590	P/S Fan Belt	BVP
122	5876100600	A/C Compressor Fan Belt	BVP
123	5876100610	Fan Belt	BVP
124	5876100620	Fan Belt	BVP
125	5876100630	Fan Belt	BVP
126	5876100771	Clutch Disc	BVP
127	5876100781	Clutch Disc	BVP
128	5876100790	Clutch Pressure Plate	BVP
129	5876100801	Clutch Disc	BVP
130	5876100810	Clutch Pressure Plate	BVP
131	5876100820	Clutch Pressure Plate	BVP
132	5876100830	Clutch Disc	BVP
133	5876100840	Clutch Disc	BVP
134	5876100850	Clutch Pressure Plate	BVP
135	5876100860	Clutch Disc	BVP
136	5876100870	Clutch Pressure Plate	BVP
137	5876100881	Water Pump	BVP
138	5876100890	Water Pump	BVP
139	5876100900	Fuel Filter	BVP
140	5876100910	Clutch Pressure Plate	BVP
141	5876100920	Clutch Disc	BVP
142	5876100930	Water Pump	BVP
143	5876101040	Clutch Pressure Plate	BVP
144	5876101050	Clutch Disc	BVP
145	5876101070	Clutch Disc	BVP
146	5876101080	Clutch Disc	BVP
147	5876101090	Clutch Release Bearing	BVP
148	5876101100	Clutch Release Bearing	BVP
149	5876101110	Clutch Release Bearing	BVP
150	5876101120	Clutch Release Bearing	BVP
151	5876110000	Fuel Filter	BVP
152	5876110030	Fuel Filter	BVP
153	5876110040	Fuel Filter	BVP
154	5876110050	Fuel Filter	BVP
155	5876110060	Oil Filter	BVP
156	5876110071	Oil Filter	BVP
157	1876101420	Clutch Disc	BVP

06 ISP 目录2025

Part Number List of ISUZU SELECT PARTS (ISP)

发动机缸套组件 LINER SET; ENG

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618243-0	1-87813766-1	-	4HK1 / 6HK1	等级 GRD=1X
2	1-87618244-0	1-87813767-1	-		等级 GRD=3X
3	1-87618245-0	1-87812775-4	-	6HK1	等级 GRD=1X
4	1-87618246-0	1-87812776-4	-		等级 GRD=3X
5	1-87618251-0	1-87814105-0	-	4BG1 / 6BG1	等级 GRD=2A
6	1-87618252-0	1-87814106-0	-	(四道环)	等级 GRD=2B
7	1-87618253-0	1-87814107-0	-		等级 GRD=2C
8	1-87618304-0		-		等级 GRD=2A
9	1-87618305-0	5-87814610-0	-		等级 GRD=2B
10	1-87618306-0		-	4JG1 / 4JG2	等级 GRD=2C
11	1-87618307-0		-		等级 GRD=3A
12	1-87618308-0	5-87814611-0	-		等级 GRD=3B
13	1-87618309-0		-		等级 GRD=3C
14	NEW 1-87618254-0	1-87813712-0	-	6WG1 直喷	等级 GRD=1X
15	NEW 1-87618255-0	1-87813713-0	-		等级 GRD=3X
16	NEW 1-87618256-0	1-87813391-4	-	6WG1 电喷	等级 GRD=1X
17	NEW 1-87618257-0	1-87813392-4	-		等级 GRD=3X

活塞组件 PISTON SET

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618384-0	-	-	4LE2	无等级 NON GRADE 附有中性缸套
2	1-87618385-0		-		等级 GRD=A 附有中性缸套
3	1-87618386-0	-	-	4JJ1	等级 GRD=B 附有中性缸套
4	1-87618387-0		-		等级 GRD=C 附有中性缸套

活塞环组件 RING SET; PISTON,STANDARD

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618468-0	5-87311082-0	NH / NK / NP / NQ / WH / WK / TF / TB / UB / UC	4JA1 / 4JB1 / 4JC1	

缸套 LINER; C/BL

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618201-0		NH / NK / NP / NL / NM /		等级 GRD=2A
2	1-87618202-0	8-97176685-0	QL / QM / QK / TF / UB /	4JA1 / 4JB1	等级 GRD=2B
3	1-87618204-0	8-97176686-0	UC / WH / WK		等级 GRD=2C
4	1-87618207-0		NH / NK / NL / NM / NP /		等级 GRD=2A
5	1-87618208-0	8-97176701-0	NQ / QL / QM / TF / UB /	4JG1 / 4JG2 / 4JG3	等级 GRD=2B
6	1-87618210-0	8-97176702-0	UC / WH / WK		等级 GRD=2C
7	1-87618212-0	8-94391602-1	ELF / FORWARD / FR / FS / FT / FV / GV / LR /	4HK1 / 6HK1	等级 GRD=1X
8	1-87618213-0	8-94391603-1	LT / LV / MR / MS / MT / NP / NQ / NN		等级 GRD=3X
9	1-87618215-0		BL / BE / ES / FR / FS /		等级 GRD=2A
10	1-87618216-0	1-11261384-1	FT / HT / NK / NP / NR /	4BG1 / 6BG1	等级 GRD=2B
11	1-87618218-0	1-11261385-1	MR / MT		等级 GRD=2C
12	1-87618221-0		BL / BE / ES / FS / FT /		等级 GRD=2A
13	1-87618222-0	1-11261242-0	FD / FR / MT / MR / NP /	4BD1 / 6BB1 / 6BD1	等级 GRD=2B
14	1-87618224-0	1-11261243-0	NQ		等级 GRD=2C

Part Number List of ISUZU SELECT PARTS (ISP)

发动机大修包 GASKET SET; ENG OVERHAUL

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618392-0	5-87817880-1	-	4HK1	无等级 NON GRADE

缸盖密封垫 GASKET; CYL HD

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618391-0	8-98114256-0	-	4HK1	包含在发动机大修包中 ALSO INCLUDED IN GASKET SET ISP P/N:1-87618392-0
2	1-87618438-0	8-97601819-5	FORWARD / FR / FS / FT / FV / GS / GV / GX / LR / LT / LV / MT / MV	6HK1	

燃油滤清器 FUEL FILTER

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618323-0	8-98036654-0	FR / FS / FT / FV / GX / NP / NQ / LV	4BG1 / 6BG1	-
2	1-87618324-0	1-13240044-1	-	6HK1 / 6RB1 / 6SD1 / 6WG1 / E120	-
3	1-87618394-0	8-98037480-0	NK / NH	4JG1 / 4JG2 / 4LB1 / 4LC1 / 4LE1 / 4LE2 / C240	-

燃油滤清器滤芯 ELEMENT KIT; FUEL FILTER

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618396-0	8-98074288-2	-	4BG1 / 4HK1 / 4JG1 / 4JG2 / 4JJ1 / 4LE1 / 4LE2 / 6BG1 / 6HK1 / 6UZ1 / 6WG1	-
2	1-87618397-0	8-98143041-0	-	4HK1 / 4JJ1 / 4LE2 / 6HK1 / 6UZ1 / 6WG1	-

机油滤清器 OIL FILTER

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618322-0	1-13240232-2	-	4BG1 / 4HK1 / 4JJ1 / 6SD1 / 6HE1 / 6BG1 / 6HK1 / 6UZ1 / 6WG1	-
2	1-87618395-0	8-98075676-1	-	4LE1 / 4LE2	-

皮带 BELT

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618456-0	8-97362815-0	-	4HK1	冷却风扇皮带 长度 L=1155mm
2	1-87618457-0	8-98042862-0	-	4HK1	冷却风扇皮带 长度 L=1199mm
3	1-87618458-0	1-13671516-0	-	6HK1 / 6SD1	水泵驱动皮带 长度 L=1240mm
4	1-87618459-0	8-98152906-0	-	6BG1 / 6HK1	水泵驱动皮带 长度 L=1210mm

发电机总成 GENERATOR ASM

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618285-0	1-81200365-1	-	4BG1 / 6BG1 / 6SD1	24V 25A
2	1-87618279-0	8-97182289-2	-	4BD1 / 4JA1 / 4JB1 / 4JG1 / 4JG2 / 4LE1 / 4LE2 / 4JG3	24V 30A
3	1-87618278-0	8-98092116-0	-	4HK1	24V 50A
4	1-87618283-0	1-81200530-4	-	4BG1 / 6BG1 / 6WG1	24V 50A
5	1-87618284-0	1-81200603-2	-	4BG1 / 6BG1 / 6SD1 / 6HK1 / 6UZ1 / 6WG1	24V 50A

Part Number List of ISUZU SELECT PARTS (ISP)

涡轮增压器总成 TURBOCHARGER ASM

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618328-0	8-98185194-1	-	4JJ1	附有配件包
2	1-87618425-0	8-98189936-2	-	4LE1 / 4LE2	附有配件包
3	1-87618258-0	8-97362839-0	-	-	-
4	1-87618259-0	8-98030217-0	-	4HK1	附有配件包
5	1-87618326-0	8-98259371-0	-	-	-
6	1-87618389-0	8-98259370-0	-	-	-
7	1-87618262-0	1-14400377-1	-	6BG1	附有配件包
8	1-87618263-0	1-14400389-1	-	-	-
9	1-87618260-0	1-14400438-1	-	-	-
10	1-87618261-0	1-14400442-1	-	-	-
11	1-87618264-0	1-14400390-2	-	6HK1	附有配件包
12	1-87618325-0	8-98257047-0	-	-	-
13	1-87618388-0	8-98257048-0	-	-	-
14	1-87618327-0	1-14400383-0	-	-	-
15	1-87618329-0	8-98192186-1	-	6WG1	附有配件包
16	1-87618398-0	8-98192213-3	-	-	-

起动机总成 STARTER ASM

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618273-0	8-97112865-2	-	3LA1 / 3LB1 / 3LD1 / 3LD2 / 4LB1 / 4LC1 / 4LE1 / 4LE2 / C240	12V 2.0kW
2	1-87618271-0	8-97042997-2	NH / NK / NQ	4JB1 / 4JG1 / 4JG2 / C240	12V 2.2kW
3	1-87618382-0	8-97349402-1	-	4JG1 / 4JG2 / 4JG3	12V 2.2kW
4	1-87618270-0	8-97137478-2	-	4JA1 / 4JB1 / 4LB1 / 4LC1 / 4LE1 / 4LE2 / 4JG1 / 4JG2 / 4JG3	24V 3.2kW
5	1-87618272-0	8-98072315-1	-	4LE1 / 4LE2	24V 3.2kW
6	1-87618383-0	8-98045027-0	-	4JJ1	24V 4.0kW
7	1-87618265-0	8-97029863-7	-	4BD1 / 4BG1	24V 4.5kW
8	1-87618266-0	8-98062041-0	-	4BG1	24V 4.5kW
9	1-87618267-0	1-81100338-0	-	6BG1	24V 4.5kW
10	1-87618268-0	1-81100401-3	-	4BG1 / 6BG1	24V 4.5kW
11	1-87618381-0	8-98070321-1	-	4HK1	24V 5.0kW
12	1-87618274-0	8-98141206-1	GV / FR / FS / FT / FV	6HK1	24V 5.0kW
13	1-87618275-0	1-81100421-5	-	6WG1	24V 7.0kW
14	1-87618276-0	1-81100341-3	CX / CY / EX	6WG1	24V 7.0kW

气门导管 GUIDE; VLV

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618357-0	1-11721013-0	MT	4BD1 / 4BG1 / 6BG1	长度 L=60mm
2	1-87618358-0	5-11721016-0	ELF / KB / NH / NK / NL / NM / NP / NQ / PH / QK / QL / QM / TB / TF / UB / UC / VF / VH / VK / WH	4JA1 / 4JB1 / 4JC1 / 4JD1 / 4JE1 / 4JF1 / 4JG1 / 4JG2 / 4JG3 / C240	长度 L=50mm
3	1-87618359-0	8-94239423-0	ELF / NH / NK / NJ / NL / NM / NN / NP / NQ / TF / UC	4JJ1	长度 L=42mm
4	1-87618360-0	8-97031749-0	-	3LA1 / 3LB1 / 3LD1 / 3LD2 / 4LB1 / 4LC1 / 4LE1 / 4LE2	长度 L=38mm
5	1-87618361-0	8-97376719-2	ELF / FORWARD / CV / CX / CY / FR / FS / FT / FV / FX / GS / GV / GX / LT / LV / LR / MR / MS / MT / NP / NQ / NR / NN	4HK1 / 6HK1 / 6UZ1	长度 L=57mm
6	1-87618393-0	8-94390780-0	ELF / FR / FS / FT / FV / GS / GV / LT / GR / NK / NP / NQ / NR	4HK1 / 6HK1	长度 L=57mm
7	NEW 1-87618356-0	1-11721012-1	EX / CV / CX / CY / LV	6WG1	长度 L=80mm

Part Number List of ISUZU SELECT PARTS (ISP)

气门座 SEAT; VLV INSERT

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618368-0	8-97037686-1	NP / NQ	4BD1 / 4BG1 / 6BG1	进气 INLET 内径 ID=41mm 外径 OD=47mm
2	1-87618369-0	5-11711028-0	NP / NQ / NK	-	排气 EXHAUST 内径 ID=33mm 外径 OD=39mm
3	1-87618378-0	8-94395888-2	ELF / FR / FS / FT / FV / GS / GV / LT / LV / LR / NP / NQ / NR	4HK1 / 6HK1	进气 INLET 内径 ID=31mm 外径 OD=38mm
4	1-87618377-0	8-98028875-0	ELF / FORWARD / FR / FS / FT / FV / GS / GV / LT / LV / LR / NP / NQ / NR	-	排气 EXHAUST 内径 ID=32mm 外径 OD=38mm
5	1-87618374-0	8-97231228-0	TB / TF / NH / NK / NL / NM / PH / QK / QL / QM / UC	4JB1 / 4JG1 / 4JG2	进气 INLET 内径 ID=34mm 外径 OD=41mm
6	1-87618375-0	8-97231229-0	ELF / TB / TF / NH / NK / NL / NM / NP / NQ / PH / QK / QL / QM / UB / UC / VF	-	排气 EXHAUST 内径 ID=30mm 外径 OD=37mm
7	1-87618379-0	8-97311378-0	ELF / NH / NK / NJ / NL / NM / NN / NP / NQ / TF / UC	4JJ1	进气 INLET 内径 ID=29mm 外径 OD=35mm
8	1-87618380-0	8-97311379-0	-	-	排气 EXHAUST 内径 ID=26mm 外径 OD=32mm
9	1-87618372-0	8-97045391-2	-	3LD1 / 3LD2 / 4LB1 / 4LC1 / 4LE1 / 4LE2	进气 INLET 内径 ID=32mm 外径 OD=38mm
10	1-87618373-0	8-97045392-0	-	-	排气 EXHAUST 内径 ID=27mm 外径 OD=33mm
11	1-87618362-0	1-11715109-1	CV / CX / CY / EX / LV	6WG1	进气 INLET 内径 ID=40mm 外径 OD=49mm
12	1-87618363-0	1-11711074-1	-	-	排气 EXHAUST 内径 ID=40mm 外径 OD=48mm
13	1-87618364-0	1-11715112-1	EX	6WG1	进气 INLET 内径 ID=40mm 外径 OD=49mm
14	1-87618365-0	1-11711077-1	-	-	排气 EXHAUST 内径 ID=40mm 外径 OD=48mm
15	1-87618370-0	5-11715023-0	KB / TB / TF / UB	C240	进气 INLET 内径 ID=34mm 外径 OD=41mm
16	1-87618371-0	5-11711026-0	-	-	排气 EXHAUST 内径 ID=28mm 外径 OD=35mm

曲轴油封 SEAL; OIL,CR/SHF

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618426-0	8-97382955-0	-	4HK1	前油封
2	1-87618427-0	8-97209342-3	-	4HK1 / 6HK1	后油封

Part Number List of ISUZU SELECT PARTS (ISP)

进/排气门 VALVE; INL / VALVE; EXH

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618344-0	1-12551165-0	-	4BD1 / 4BG1 / 6BG1	进气 INLET
2	1-87618345-0	1-12552111-0	-	-	排气 EXHAUST
3	1-87618346-0	5-12551028-2	-	C240	进气 INLET
4	1-87618347-0	5-12552034-2	-	-	排气 EXHAUST
5	1-87618348-0	8-97102123-1	-	3LD1 / 3LD2 / 4LB1 / 4LC1 / 4LE1 / 4LE2	进气 INLET
6	1-87618349-0	8-97045410-3	-	-	排气 EXHAUST
7	1-87618350-0	8-94133275-2	NH / NK / NL / NM / QK / QL / QM / TB	4JG1 / 4JG2	进气 INLET
8	1-87618351-0	8-97065970-0	-	-	排气 EXHAUST
9	1-87618352-0	8-94395882-2	ELF / FORWARD / FG / FR / FS / FT / FV / GS / GV / LT / LR / MR / MS / MT / NP / NQ / NR / NN	4HK1 / 6HK1	进气 INLET
10	1-87618353-0	8-97209876-4	-	-	排气 EXHAUST
11	1-87618354-0	8-98016973-0	ELF / NH / NK / NJ / NL / NM / NN / NP / NQ / TF	4JJ1	进气 INLET
12	1-87618355-0	8-98016974-1	-	-	排气 EXHAUST
13	NEW 1-87618340-0	1-12551162-4	EX / CV / CX / CY / LV	6WG1 电喷	进气 INLET
14	NEW 1-87618341-0	1-12552100-3	-	-	排气 EXHAUST
15	NEW 1-87618342-0	1-12551151-6	-	-	进气 INLET
16	NEW 1-87618343-0	1-12552109-2	-	-	排气 EXHAUST

气门油封 SEAL; VLV GUIDE

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618429-0	8-97376720-0	FORWARD / ELF / CV / CX / CY / EX / FR / FS / FT / FV / FX / GS / GV / GX / LT / LV / LR / MR / MS / MT / NP / NQ / NL / NM / NN	4HK1 / 6HK1 / 6UZ1	

节温器 THERMOSTAT

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618430-0	8-97300790-3	ELF / FORWARD / FR / FS / FT / FV / GS / GV / LR / LV / MR / MS / NM / NN / NP / NQ	4HK1	阀门打开温度: 82℃
2	1-87618431-0	8-97300787-3	ELF / FORWARD / FR / FS / FT / FV / GS / GV / LR / LV / MR / MS / NJ / NK / NL / NM / NN / NP / NQ	4HK1	阀门打开温度: 85℃
3	1-87618432-0	8-98295921-0	FORWARD / FR / FS / FT / FV / FX / GV / GX / LT / LV / LR / MT / MV	4HK1 / 6HK1	阀门打开温度: 82℃
4	1-87618433-0	8-97602048-3	FORWARD / FR / FS / FT / FV / FX / GV / GX / LT / LV / LR / MT / MV	6HK1	阀门打开温度: 82℃

水泵总成 PUMP ASM; WATER,W/GASKET

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618437-0	8-98022822-1	-	4HK1	附有垫片
2	1-87618435-0	1-13650133-4	-	6HK1	附有垫片
3	1-87618436-0	8-98229799-0	-	4JJ1	附有垫片
4	NEW 1-87618471-0	8-98047688-4	-	4JJ1	附有垫片
5	NEW 1-87618472-0	5-87311349-0	-	4LE1 / 4LE2	附有垫片

Part Number List of ISUZU SELECT PARTS (ISP)

曲轴 CRANKSHAFT

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618434-0	8-98029270-1	ELF / FORWARD / FR / FS / FT / FV / GV / LR / MR / MS / NN / NP / NQ	4HK1	安装有3个定位销

曲轴瓦大修包 METAL KIT; CRANKSHAFT

序号 No.	五十铃优选零件 ISUZU SELECT PARTS		五十铃纯正零件 ISUZU GENUINE PARTS		适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
	零件号 PART NUMBER	数量 QTY	零件号 PART NUMBER	数量 QTY			
1	1-87618418-0	上瓦: 5片 下瓦: 5片 (1盒5对)	8-97372076-1	上瓦: 1片 下瓦: 1片 (1盒1对)	-	-	蓝色 / 错口
2	1-87618421-0	上瓦: 7片 下瓦: 7片 (1盒7对)	-	-	-	-	-
3	1-87618419-0	上瓦: 5片 下瓦: 5片 (1盒5对)	8-97372077-1	上瓦: 1片 下瓦: 1片 (1盒1对)	FORWARD / FR / FS / FT / FV / GV / LT / LR / NP / NQ / NK / NM	4HK1 / 6HK1	黑色 / 错口
4	1-87618422-0	上瓦: 7片 下瓦: 7片 (1盒7对)	-	-	-	-	-
5	1-87618420-0	上瓦: 5片 下瓦: 5片 (1盒5对)	8-97372078-1	上瓦: 1片 下瓦: 1片 (1盒1对)	-	-	棕色 / 错口
6	1-87618423-0	上瓦: 7片 下瓦: 7片 (1盒7对)	-	-	-	-	-
7	1-87618449-0	上瓦: 5片 下瓦: 5片 (1盒5对)	8-97071661-0	上瓦: 5片 下瓦: 5片 (1盒5对)	-	4BD1 / 4BG1	包含止推垫片: 4片 错口
8	1-87618444-0	上瓦: 7片 下瓦: 7片 (1盒7对)	1-11510074-1	上瓦: 7片 下瓦: 7片 (1盒7对)	FS / FT / MR / MT	6BD1 / 6BG1	包含止推垫片: 4片 错口
9	1-87618463-0	上瓦: 7片 下瓦: 7片 (1盒7对)	1-11510093-5	上瓦: 7片 下瓦: 7片 (1盒7对)	CX / EX / LV	6WG1	包含止推垫片: 4片 错口

连杆瓦组件 METAL SET; CONN ROD

序号 No.	五十铃优选零件 ISUZU SELECT PARTS		五十铃纯正零件 ISUZU GENUINE PARTS		适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
	零件号 PART NUMBER	数量 QTY	零件号 PART NUMBER	数量 QTY			
1	1-87618408-0	上瓦: 1片 下瓦: 1片 (1盒1对)	8-97616358-0	上瓦: 1片 下瓦: 1片 (1盒1对)	FORWARD / FR / FS / FT / FV / GV / LT / NP / NQ / MT	4HK1 / 6HK1	绿色 / 对口
2	1-87618411-0	上瓦: 1片 下瓦: 1片 (1盒1对)	8-97616359-0	上瓦: 1片 下瓦: 1片 (1盒1对)	-	-	黄色 / 对口
3	1-87618450-0	上瓦: 1片 下瓦: 1片 (1盒1对)	9-12271608-0	上瓦: 1片 下瓦: 1片 (1盒1对)	BE / BL / ES / FR / FS / FT / HT / LR / LT / MR / MT / NK / NP / NR	4BA1 / 4BB1 / 4BC2 / 4BD1 / 4BG1 / C330 / 6BB1 / 6BD1 / 6BG1	错口
4	1-87618466-0	上瓦: 1片 下瓦: 1片 (1盒1对)	1-12271096-0	上瓦: 1片 下瓦: 1片 (1盒1对)	CV / CX / CY / EX / LV	6WG1	错口

Part Number List of ISUZU SELECT PARTS (ISP)

凸轮轴瓦 METAL; CM/SHF

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618414-0	8-97386189-0	FORWARD / CV / CX / CY / FR / FS / FT / FV / FX / GS / GV / LT / LV / LR / MR / MS / MT / NK / NN / NP / NQ	4HK1 / 6HK1	宽度 B=16mm
2	1-87618415-0	8-97602699-0	FORWARD / CV / CX / CY / FR / FS / FT / FV / FX / GS / GV / GX / LT / LV / LR / NR	6HK1	宽度 B=26mm
3	1-87618452-0	9-11691048-1	ES / FR / FS / FT / BL / BE / LR / LT / HT / MR / NK / NP / NQ / NR	4BA1 / 4BD1 / 4BC2 / 4BG1 / 6BD1 / 6BG1 / C330	更换时会同时使用 到两个件号
4	1-87618453-0	9-11693035-1			

止推垫片大修包 WASHER KIT; THRUST,CR/SHF

序号 No.	五十铃优选零件 ISUZU SELECT PARTS	五十铃纯正零件 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
	零件号 PART NUMBER	数量 QTY	零件号 PART NUMBER	数量 QTY	
1	1-87618424-0	3片 (1袋)	8-97386548-0	1片	FORWARD / FR / FS / FT / FV / GS / GV / LT / LV / LR / MR / MS / MT / NJ / NK / NL / NM / NN / NP / NQ
			8-97386549-0	2片	4HK1 / 6HK1 对应ISP零件号: 1-87618416-0 8-97386549-0 对应ISP零件号: 1-87618417-0

电热塞 PLUG; GLOW

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618439-0	1-82513043-2	CX / CY / EX / FR / FS / FT / FV / GV / LT / LV	4BG1 / 4JG1 / 4JG2 / 6BG1 / 6SD1	电压: 20.5V
2	1-87618440-0	1-82513045-2	-	4BG1 / 6BG1 / 6WG1	电压: 23.0V
3	1-87618441-0	8-94133759-9	ELF / NH / NK / NL / NM / NP / NQ / PH / QL / QM / QK / TF	4BG1 / 4JG1 / 4JG2 / 4JG3 / 4LE2 / 6BG1	电压: 11.0V
4	1-87618442-0	8-94319700-4	TB / TF	2KC1 / 3AA1 / 3AB1 / 3AD1 / 3KA1 / 3KB1 / 3KC1 / 3KC2 / 3KR1 / 3KR2 / 4FE1 / C240	电压: 11.0V
5	1-87618443-0	8-94390777-6	ELF / FORWARD / CV / CX / CY / FR / FS / FT / FV / FX / GS / GV / LT / LV / LR / MR / MS / MT / MV / NH / NJ / NK / NL /	4HK1 / 6HK1 / 6UZ1	电压: 23.0V

传感器 SENSOR

序号 No.	五十铃优选零件号 ISUZU SELECT PARTS	五十铃纯正零件号 ISUZU GENUINE PARTS	适用车型 VEHICLE MODEL	适用机型 ENGINE MODEL	备注 REMARKS
1	1-87618475-0	8-97606943-0	FORWARD / ELF / CV / CX / CY / EX / FR / FS / FT / FV / FX / GS / GV / GX / LT / LV / LR / MR / MS / MT / NJ / NK / NL / NM / NN / NP / NQ	4HK1 / 4HV1 / 6HK1 / 6UZ1 / 6WG1	
2	1-87618476-0	8-98019024-0	FORWARD / ELF / FR / FS / FT / FV / FX / GS / GV / GX / LT / LV / LR / MR / MS / MT / MV / NH / NJ / NK / NL / NM / NN / NP / NQ / TF / UC /	4HK1 / 4JJ1 / 4LE2 / 6HK1	
3	1-87618477-0	8-98183621-0	ELF / CV / CX / CY / EX / NH / NK / NL / NM / NN / NP / PH / QK / QL / QM / TF / UC	4JG3	

COMLEN



28 YEARS BEST EXPERIENCE

COMLEN BRAND TRUCK SPARE PARTS

Quality assurance

Professional services

